



Tekla Structures

System Guide



Product version 21.0
March 2015

©2015 Tekla Corporation

Contents

1	Optimizing Tekla Structures performance.....	5
1.1	System memory.....	5
1.2	Graphics card.....	6
1.3	Modeling tips for large models.....	6
2	Tekla Open API.....	8
3	Files and folders.....	9
3.1	Initialization files.....	10
	Typical initialization files and their reading order.....	10
	Global default environment settings - env_global_default.ini.....	14
	Local environment settings - env_<environment>.ini.....	14
	Role settings - role_<role>.ini.....	14
	Modifying the user.ini file	15
	Creating customized initialization files and startup shortcuts.....	16
	Initialization files included in customized initialization files.....	18
3.2	Files storing options and advanced options.....	18
	Settings in the Options dialog box.....	19
	Settings defined by advanced options.....	32
	List of user-specific advanced options.....	33
	Changing advanced option settings	38
3.3	Input files.....	39
	Customizing user-defined attributes.....	39
	The environment database file.....	40
	Updating definitions of user-defined attributes in a model.....	41
	Objects.inp properties.....	41
	User-defined attributes affecting numbering.....	43
	Example: Creating and updating a user-defined attribute.....	43
	Showing plates as flat bars in drawings and reports.....	46
	Defining flat bar sizes with Fltprops.inp.....	47
	Defining unfolding parameters.....	47
	Unfolding parameter properties.....	48
3.4	Data files.....	49
3.5	Message files.....	50
	Customizing message files.....	50
	Example: Modifying a message file.....	51
3.6	Standard files.....	51
	List of standard files saved with Save defaults command.....	52
3.7	Properties files.....	52
3.8	Catalog files.....	53
3.9	Font files.....	54

3.10	Symbol files.....	55
3.11	Files related to templates, reports and drawings.....	55
3.12	Image files.....	56
3.13	Log files.....	57
	Viewing a log file.....	58
	Viewing parts listed in a log file.....	59
	The numbering.history log file.....	59
	Numbering series in the numbering.history log file.....	61
3.14	Model folder files and file name extensions.....	62
3.15	Checking and changing Tekla Structures file and folder locations (Directory Browser).....	83
3.16	Folder search order.....	84
3.17	Project and firm folders.....	86
3.18	Location of environment files.....	87
3.19	Location of certain files in hidden folders.....	87
3.20	Macros.....	89
	Recording, editing and running macros.....	89
	Adding a customized toolbar button for a macro.....	90
4	Model dump.....	91
4.1	Exporting a model dump.....	91
4.2	Importing a model dump.....	92
5	Disclaimer.....	93

1 Optimizing Tekla Structures performance

To optimize Tekla Structures performance, you should consider the following items especially when you are handling large and complex models:

- your hardware setup
- **Speed and Accuracy** settings in the **Advanced Options** dialog box.
- modeling practices.

For more detailed information on hardware setup, see hardware recommendations in Tekla User Assistance Support Articles: [Hardware recommendations](#)

See also the **Hardware and operating system** topics on the [Tekla Discussion Forum](#).

See also [System memory on page 5](#)

[Graphics card on page 5](#)

[Modeling tips for large models on page 6](#)

1.1 System memory

Large models consume more memory. As a 64-bit system is able to utilize more memory than a 32-bit system, 64-bit Tekla Structures on a 64-bit operating system is recommended.

See also [Optimizing Tekla Structures performance on page 5](#)

1.2 Graphics card

Rendering in Tekla Structures uses OpenGL technology, so graphics cards with good hardware support for OpenGL give the best performance. Up-to-date display drivers are very important so you should regularly check that you have the latest driver installed.

If you suspect that your graphics card is causing problems with displaying objects, set the `XS_USE_SOFTWARE_RENDERING` advanced option to `TRUE`. This may solve the display problems but may reduce performance.

You can test your graphics card performance with Steelmark, an application developed by Tekla. Steelmark tests how fast your computer handles graphical information typically used in Tekla Structures. You can download Steelmark on the Tekla Extranet.

See also `XS_USE_SOFTWARE_RENDERING`

[Optimizing Tekla Structures performance on page 5](#)

[Tekla Structures graphics hardware test](#)

1.3 Modeling tips for large models

Consider the following modeling tips when you handle large models:

Modeling item	Tips
Coordinate system	<ul style="list-style-type: none">• Do not place the model far away from the origin. More calculations are required when coordinates are big.• Mark global coordinates as labels instead of actually using them during modeling.• If you need to use building site coordinates, drop the first digits if they are always the same. For example, instead of coordinate 758 375 6800, use 375 6800.
Work area and visibility	<ul style="list-style-type: none">• Keep the work area as small as possible.• Show only the required parts in views.• Use view filters to control the visibility of parts.
Views	<ul style="list-style-type: none">• Close unnecessary views.• Close all views when you save large models.
Round objects	<ul style="list-style-type: none">• Create holes with the Create bolts command instead of using part cuts with round beams.• Use studs to model small straight round objects instead of small round beams.• Model lifting hooks and other embeds with reinforcement bars instead of round polybeams.
Hollow core profiles	<ul style="list-style-type: none">• Use simple fixed (non-parametric) profiles.

Modeling item	Tips
	<ul style="list-style-type: none"> • Use chamfers for curved corners.
Custom components	<ul style="list-style-type: none"> • Do not create overly complex custom components. When used in great numbers they consume a lot of memory.
Numbering	<ul style="list-style-type: none"> • Do not number the whole model in one go. Numbering all objects in large models may take a considerable amount of time.
Model database	<ul style="list-style-type: none"> • If your model file is getting large, repairing the model database can help to reduce the file size considerably and therefore help with memory problems.
Firm and Project folders	<ul style="list-style-type: none"> • Save Firm and Project folders locally on the hard drive of your computer instead of a network drive. This saves time if network speed is slow. <p>When working in the multi-user mode, ensure that the folders are synchronized on all users' hard drives so that important data is not lost or changed.</p>

See also

2 Tekla Open API

Tekla Open API is a specialized Application Programming Interface (API) developed by Tekla that enables you to develop applications and additional functionality on the Tekla modeling platform and integrate it into your own environment. Tekla Open API is implemented using Microsoft .NET technology.

Applications that are developed with Tekla Open API to work in conjunction with Tekla Structures are called *extensions*.

With Tekla Open API you can:

- Record and run user interface actions
By recording and running user interface actions you can automate routine tasks, such as creating daily reports.
- Create automation tools
You can create automation tools for frequently needed objects. With automation tools you can, for example, create basic structures or add typical details to drawings.
- Integrate Tekla Structures to other software
You can utilize the Tekla Open API and .NET in transferring information between Tekla Structures and other software, such as Analysis & Design software.
- Create new functionality
With Tekla Open API, you can create tools that add new functionality to Tekla Structures.

For more information on Tekla Open API and extensions, see:

- TeklaOpenAPI_Reference.chm help in the `.. \ProgramData\Tekla Structures\<version>\help\enu` folder
- .NET startup package in [Tekla Downloads](#) product download service.
- Extensions in [Tekla Warehouse](#).
- Extensions in Tekla User Assistance.

3 Files and folders

This section explains where Tekla Structures stores information. It describes the file types Tekla Structures contains, where they are located, and how they should be used.

Tekla Structures contains a large amount of files that affect the way the software works. It is important to know which file controls which functionality, and also which files we do not recommend that you touch.

The initialization file reading order is also very important. You need to know the order in which the files are read when you open Tekla Structures, so that you do not do unnecessary modifications in the files.

- See also**
- [Initialization files on page 10](#)
 - [Input files on page 38](#)
 - [Files storing options and advanced options on page 18](#)
 - [Data files on page 49](#)
 - [Message files on page 50](#)
 - [Standard files on page 51](#)
 - [Properties files on page 52](#)
 - [Catalog files on page 53](#)
 - [Font files on page 54](#)
 - [Symbol files on page 55](#)
 - [Files related to templates, reports and drawings on page 55](#)
 - [Image files on page 56](#)
 - [Log files on page 57](#)
 - [Model folder files and file name extensions on page 62](#)
 - [Checking and changing Tekla Structures file and folder locations \(Directory Browser\) on page 82](#)
 - [Folder search order on page 84](#)
 - [Project and firm folders on page 86](#)

[Location of environment files on page 87](#)

[Location of certain files in hidden folders on page 87](#)

[Macros on page 88](#)

3.1 Initialization files

Initialization files are used for defining Tekla Structures start-up parameters and default settings. They contain *advanced options* that are used for configuring Tekla Structures for different standards, and for your or your company's style of working.

Tekla Structures automatically creates the necessary initialization files during installation. The number of initialization files it creates depends on how many country-specific environments you choose to install.

See also [Advanced Options Reference Guide](#)

Typical initialization files and their reading order

Below is a list of all the typical initialization files that are read when Tekla Structures is started. The numbers indicate their reading order at startup. If there are conflicting settings, the ones read later override the ones read earlier.



Changing an advanced option value in `.ini` files located outside the model folder does not affect the existing models. You can only update advanced options in the **Advanced Options** dialog box or in the `options.ini` file located in model folder; not from an `options.ini` file located in folders defined for the advanced options `XS_FIRM` or `XS_PROJECT`. The `.ini` files are read also when you open an existing model, but only new advanced options that do not exist in `options_model.db` or `options_drawings.db` are inserted, for example, such options that are not yet in the **Advanced Options** dialog box but have been added in the software.



To check the files that have been read and their reading order, go to **Tools --> Display Log File --> Session History** .

File and reading order	Description
1. fonts_<lang>.ini	<p>This file is optional, and it is only needed for languages using special characters. One example is the fonts_jpn.ini file for the Japanese language.</p> <p>This file is read from Tekla Structures\<version>\nt\bin\ if it is available. It is installed to the ..\nt\bin folder when Tekla Structures is installed.</p> <p>NOTE: Do not change these settings.</p>
2. teklastructures.ini	<p>The file teklastructures.ini starts Tekla Structures. It is read from ..\Program Files\Tekla Structures\<version>\nt\bin\.</p> <p>This file contains basic system settings, such as the location of software and environment files. This file is installed to the ..\nt\bin folder when Tekla Structures is installed. It is always read at Tekla Structures startup.</p> <p>NOTE: Do not change these settings.</p>
3. lang_<lang>.ini	<p>This file contains the language settings. It is read from ..\Program Files\Tekla Structures\<version>\nt\bin\.</p> <p>This file is installed to the ..\nt\bin folder when Tekla Structures is installed.</p> <p>Which lang_<lang>.ini files exist in the ..\nt\bin folder depends on which languages you have selected to install during the software installation.</p> <p>The language that is read depends on the language you have selected in Tools --> Select Language in the previous Tekla Structures session.</p> <p>NOTE: Do not change these settings.</p>
4. env_global_default.ini	<p>This file is used as a default for all environments and contains the global settings. The settings in the env_global_default.ini provide the basics for all environment settings globally. The settings in this file can be localized and specified differently in an environment-specific initialization file that is read later than this file.</p> <p>This file is always read at Tekla Structures startup from ..\ProgramData\Tekla Structures\<version>\environments\common\ and is installed there from the common environment installation package.</p> <p>NOTE: Do not change these settings.</p>

File and reading order	Description
<p>5. env_<environment>.ini</p>	<p>The env_<environment>.ini files contain all the advanced options that have environment-specific settings. They are read from ..\ProgramData\Tekla Structures\<version>\environments\<environment>\.</p> <p>The env_<environment>.ini files that exist on your computer depends on which environment packages you have installed. Which env_<environment>.ini file is read depends on the environment that you select in the Tekla Structures the startup dialog box.</p> <p>For example, this file defines that the US imperial environment uses imperial units, shows the fractions correctly, and understands input as imperial. In metric environments metric units are used.</p> <p>NOTE: Do not change these settings.</p>
<p>6. role_<role>.ini</p>	<p>The role_<role>.ini files contain all the advanced options that have typical role-specific settings. They are read from ..\ProgramData\Tekla Structures\<version>\environments\<environment>\.</p> <p>The available roles depend on the environments you have installed.</p> <p>You can select the role in the Tekla Structures the startup dialog box.</p> <p>NOTE: Do not change these settings.</p>
<p>7. All .ini files defined in shortcut/command line with -i <name>.ini</p>	<p>Usually none.</p>
<p>8. company.ini</p>	<p>The company.ini file is useful especially for big companies that want to unify certain enterprise-level settings. This file is read from a folder specified with the advanced option XS_COMPANY_SETTINGS_DIRECTORY. This file is read only if the advanced option XS_COMPANY_SETTINGS_DIRECTORY is set.</p> <p>This file is created by the system administrator when necessary, it is not created by the installation.</p>
<p>9. user.ini</p>	<p>The user.ini file is where you can save your personal user settings.</p> <p>This file is located in the same location as the user-specific options.bin file, for example, C:\Users\<user>\AppData\Local\Tekla Structures\<version>\UserSettings.</p>

File and reading order	Description
	<p>The <code>user.ini</code> is created in the above mentioned location when you start Tekla Structures for the first time and create and save a model using the current version. It is read when you start Tekla Structures.</p> <p>The changes you make in the advanced options in the Advanced Options dialog box override the settings in all other initialization files, if the advanced option exists in both locations.</p> <p>If <code>user.ini</code> has system options they are read always when Tekla Structures is opened.</p> <p>If <code>user.ini</code> has model-specific options they are used when new model is created.</p> <p>If <code>user.ini</code> has user-specific options they are used when Tekla Structures is used for the first time.</p>
10. <code>options.ini</code> in system folder	The folder is specified with the advanced option <code>XS_SYSTEM</code> .
11. <code>options.ini</code> , firm-specific, if any exists 12. <code>options.ini</code> , project-specific, if any exist	<p>The <code>option.ini</code> files containing firm- or project-specific model settings are saved in and read from user-defined locations specified with the advanced options <code>XS_FIRM</code> and <code>XS_PROJECT</code>. They work in the specified way for the firm in question, or for the specified project if the model has been set up to read settings from these locations, and if the user has manually moved the <code>options.ini</code> file to these locations. An <code>options.ini</code> is created in the firm or project folder when you copy or move it there.</p> <p>Updating of model-specific and user-specific advanced options can only be done from the Advanced Options dialog box or <code>options.ini</code> located in model folder, not from the firm- or project-specific <code>options.ini</code> files.</p> <p>The <code>options.ini</code> in the firm or project folder is read when you start Tekla Structures or open the model.</p>
13. <code>options.ini</code> , model-specific	The <code>options.ini</code> in the model folder.

See also [Settings defined by advanced options on page 32](#)

[Creating customized initialization files and startup shortcuts on page 16](#)

Global default environment settings – env_global_default.ini



Do not modify the `env_global_default.ini` file. If you need to modify some environment settings, copy the needed advanced options from this file to your `user.ini` file and modify the settings there, or modify the settings in the **Advanced Options** dialog box.

This file defines the global defaults for advanced options. Please see the environment settings file `env_<environment name>.ini` and the role settings file `role_<role name>.ini` files for advanced options that are set according to your local standards. The local files override the advanced options set in `env_global_default.ini`.

If the advanced option in the file is preceded by "rem", the software defaults are used and shown as the value. The outdated advanced options are listed at the end of the file.

See also [Typical initialization files and their reading order on page 10](#)

Local environment settings – env_<environment>.ini



Do not modify the `env_<environment>.ini` file. If you need to modify some settings, copy the needed advanced options from this file to your `user.ini` file and modify the settings there, or modify the settings in the **Advanced Options** dialog box.

This file contains advanced options that are set according to local standards and are different from the global defaults. The Global default environment settings file `env_global_defaults.ini` contains a complete listing of advanced options. The local files override the advanced options set in `env_global_default.ini`.

See also [Typical initialization files and their reading order on page 10](#)

Role settings – role_<role>.ini



Do not modify the `role_<role>.ini` file. If you need to modify some settings, copy the needed advanced options from this file to your `user.ini` file

and modify the settings there, or modify the settings in the **Advanced Options** dialog box.

This file contains advanced options that are set according to typical role requirements in your local area. These settings are different from your environment settings in `env_<environment>.ini`. The global default environment settings file `env_global_defaults.ini` contains a complete listing of advanced options. The advanced option settings in `role_<role>.ini` override the ones in `env_<environment>.ini`

See also [Typical initialization files and their reading order on page 10](#)

Modifying the user.ini file



We recommend that you add in the `user.ini` file only system-specific advanced options. You can also add model-specific advanced options, but these settings only affect new models that you create. Putting user-specific advanced options in `user.ini` may not work as desired as `options.bin` is loaded after `user.ini` and may override the value.

To add an advanced option in the `user.ini` file:

1. Right-click the `user.ini` file in Windows Explorer and click **Open with...**. Select a standard text editor from the list of available programs.
2. On a new line, enter `set`, then a space, then the name of the advanced option followed by an equal sign, and then the value in a single line.

Tekla Structures only reads lines in the initialization file that start with `set`.

3. Save `user.ini`.
4. Restart Tekla Structures for the changes to take effect.

Possible values	Example
TRUE FALSE	<code>set XS_DISABLE_WELD_PREP_SOLID=TRUE</code> <code>set</code> <code>XS_UNDERLINE_AFTER_POSITION_NUMBER_IN_HARDSTA</code> <code>MP=FALSE</code>
1	<code>set XS_SINGLE_CLOSE_DIMENSIONS=1</code>
0	<code>set XS_SINGLE_USE_WORKING_POINTS=0</code>
string value	<code>set</code> <code>XS_USER_DEFINED_BOLT_SYMBOL_TABLE=bolt_symbol</code> <code>_table.txt</code>

Possible values	Example
switches	<pre>set XS_ASSEMBLY_FAMILY_POSITION_NUMBER_FORMAT_STRING=%%TPL:PROJECT.NUMBER%%</pre> <p>Use two switches.</p>



When you are moving to a new version of Tekla Structures, you can use the Migration Wizard to automatically copy your `user.ini` file to the new version.

The Migration Wizard appears once you start Tekla Structures for the first time after installation. For more information on the Migration Wizard, see the Tekla Structures installation guide.

See also [Location of certain files in hidden folders on page 87](#)
[Typical initialization files and their reading order on page 10](#)

Creating customized initialization files and startup shortcuts

You can use shortcuts for starting `teklastructures.exe` with initializations that you have customized, for example, for certain customers or projects. The Tekla Structures installation automatically creates shortcuts for the selected environments.


We recommend that only administrators create the customizations and the necessary shortcuts. Otherwise, your settings may differ from the settings defined for your firm, or for the particular project you are working for.

To create a customized initialization file and a project-specific shortcut:

1. Open the `user.ini` file using any standard text editor.
2. Save the file with a new name, for example, `customer.ini` or `project.ini`.
3. Modify the file by adding the required settings.
4. Save the modified initialization file.
5. Open the Windows **Start** menu, select **All Programs --> Tekla Structures <version>** and right-click **Tekla Structures <version>**.
6. Select **Copy** from the pop-up menu.
7. Paste the shortcut to your desktop.
8. Select the shortcut and right-click.
9. Select **Properties...** from the pop-up menu.

10. Modify the **Target** of the shortcut by adding the required project initialization information to it.

First enter the path to the current `teklastructures.exe`, then the desired parameters. In the following example, the name of the customized initialization file is `project1.ini`.



You can use the following parameters in shortcuts:

- `-i <initialization_file>`: The initialization file to be read during startup after the `<role>.ini` file, for example, `-i \\MyServer\MyProject\Project1.ini`. You can repeat this parameter as many times as you need, and this way enter as many initialization files you need.
- `<model_to_be_opened>`: Full path to the model to be opened automatically, for example, `"C:\TeklaStructuresModels\New model 1"`.

The settings in `user.ini` and `option.ini` files override the settings defined in the shortcuts using the parameter `-i <initialization_file>`

The maximum length of a shortcut is 256 characters. If you have problems with the length, you can call all other necessary initialization files from your customized initialization file instead of adding them to the shortcut.

See also [Initialization files included in customized initialization files on page 18](#)
[Typical initialization files and their reading order on page 10](#)

Initialization files included in customized initialization files

Initialization files can include or call other initialization files. You can use this functionality to create shortcuts for different purposes, for example, to have customized setup files depending on the client you are working for in a project such as fabricators.

Below is an example of a customized project initialization file that calls other initialization files.

`MyProject.ini`

```
// The project is based on the default US imperial settings
call c:\ProgramData\Tekla Structures\19.0\environments\usimp\env_usimp.ini
// ..but our company policy requires these changes
call c:\CompanySettings\OurPolicy.ini
// ..and the fabricator requires something
call c:\Fabricators\Fabricator1.ini
// ..and then we let users to make some changes (bg color etc.)
call c:\Users\user_%USERNAME%.ini
```

The project shortcut for `MyProject`:

```
C:\Program
Files\Tekla Structures\19.0\nt\bin\TeklaStructures.exe -i \\MyServer
\MyProject\MyProject.ini \\MyServer\MyProject\MyModel\MyModel.db1
```

See also [Creating customized initialization files and startup shortcuts on page 16](#)

3.2 Files storing options and advanced options

When a new model is created, Tekla Structures reads model-specific option and advanced option values from the `standard.opt` file, and from the `.ini` files in a certain reading order, and creates the databases `options_model.db` and `options_drawings.db`, and the `options.ini` file under the model folder.

When you change a model-specific option or advanced option and press **OK** or **Apply** in the **Options** or **Advanced Options** dialog box, the settings are taken into use (otherwise you will

get a warning message). The updated model-specific option or advanced option settings are saved in `options_model.db` and `options_drawings.db` under model folder when the model is saved. In addition, there are also some special model-specific advanced options that can be updated from the `options.ini` file located in the model folder, for example, new advanced options that are not yet in the **Advanced Options** dialog box.

When you change a user-specific option or advanced option, and press **OK** or **Apply** in the **Options** or **Advanced Options** dialog box, the settings are saved in `options.bin` in `..\Users\\AppData\Local\Tekla Structures\\UserSettings`.

You can change model-specific advanced options only in the **Advanced Options** dialog box or in the `options.ini` file that is located in model folder.

You can change user-specific advanced options only in the **Advanced Options** dialog box.

You can change model- and user-specific options only in the **Options** dialog box manually or by loading `standard.opt` file values in the dialog box.

You can save your own settings in the **Options** dialog by using the **Save** button. Then the `standard.opt` file is saved in the `\attributes` folder under the model folder.



You can create a complete list of advanced options in a text file by clicking **Write to file** in the **Advanced Options** dialog box. The list shows the name of the advanced option, current value and type.



Changing an advanced option value in `.ini` files located outside the model folder does not affect the existing models. You can only update advanced options in the **Advanced Options** dialog box or in the `options.ini` file located in model folder; not from an `options.ini` file located in folders defined for the advanced options `XS_FIRM` or `XS_PROJECT`. The `.ini` files are read also when you open an existing model, but only new advanced options that do not exist in `options_model.db` or `options_drawings.db` are inserted, for example, such options that are not yet in the **Advanced Options** dialog box but have been added in the software.

See also [Settings in the Options dialog box on page 19](#)

[Settings defined by advanced options on page 32](#)

Settings in the Options dialog box

The **Options** dialog box (**Tools > Options > Options...**) contains the current values for a number of Tekla Structures settings.




Check the settings before you start modeling and change them, if necessary.

The model-specific settings in this dialog box are saved in the `options_model.db` and `options_drawings.db` databases in the model folder, and the user-specific settings in `options.bin` in your local <user> folder.

You can also save your own settings by using the **Save** button. Then the `standard.opt` file is saved in the `\attributes` folder under model folder. You may want to copy this file to your firm folder. When you create a model, the `standard.opt` is read from the firm folder.

The options in the **Options** dialog box are described below.

Clash check page Settings on this page are model-specific.

Option	Description
Clash check between bolt and bolted part	<p>Defines whether the model is checked for clashes that occur between bolts and the related bolted parts.</p> <p>If you select Yes, Tekla Structures will check the bolts against the real geometry of the bolted part profiles including roundings, and using the real bolt dimensions.</p>
	<p>Defines the clash check clearance area for bolts.</p> <p>If you do not enter a value, Tekla Structures uses the default value 1.00.</p> <p>If you clear the check boxes, the clearance will be zero.</p>
	<p>Defines the minimum clearance or the allowed overlap for reinforcing bars when they are checked against other reinforcing bars.</p> <p>To allow reinforcing bars to overlap, enter a negative value.</p> <p>If you clear the check box, the clearance will be zero.</p>
	<p>Defines the reinforcing bar cover thickness.</p> <p>Tekla Structures checks the cover thickness against the part that the reinforcing bar belongs to. Tekla Structures only checks the distance from bar side to part surface. Tekla Structures does not check the distance from bar end to part surface. If the bar penetrates a part surface, a clash is reported, even if the bar is completely inside a cast unit or pour.</p> <p>If you clear the check box, Tekla Structures will not check the cover thickness.</p>

Components page Tekla Structures uses the information on the **Components** tab when it creates parts using components.

Component properties defined in component dialog boxes override these settings. Tekla Structures only uses these settings if the corresponding boxes in the component dialog boxes are empty.

If you change settings here, Tekla Structures only applies the new settings to components you subsequently create. Components you created prior to changing the preferences are not affected.

Settings on this page are model-specific.

Option	Description
Profile names	<p>Defines parametric profile prefixes for plates. It is important that profile names are set up correctly so that you can use filters and wizards effectively.</p> <p>Profile names must exist in the profile catalog. If you want to use a parametric profile that does not have a name in the catalog, first add it to the Profile Catalog, then enter it here. Tekla Structures uses the Folded plate prefix when you use the folded plates in components.</p>
Bolts	<p>In components, Tekla Structures uses Factor of bolt edge distance and Compare edge distance to to check that the bolts it creates are not too close to the edge of a part, and warns you if they are. Check that Factor of bolt edge distance is set according to the standard you are using. The default edge distance setting depends on your environment.</p> <p>Compare edge distance defines whether the edge distance checks are based on bolt or hole diameter.</p> <p>To define the default bolt properties to use in connections, select a Bolt standard and Bolt size.</p>
Parts	<p>Part material defines the default part material grade.</p> <p>Part start numbers defines start numbers for parts that are Welded to primary and Welded to secondary, Loose parts, and Assembly loose parts.</p> <p>Cross-check these settings against the numbering series you define to make sure they do not overlap. If they overlap, Tekla Structures may create two non-identical parts with the same part number. This generates an error in the log file <code>numbering.history</code>.</p>

Drawing dimensions page

Settings on this page are model-specific.

Option	Description
Exaggeration	<p>This setting defines the default values for Exaggeration limit and Exaggeration scaling.</p> <p>When you enable the exaggeration of the dimensions, a drawing dimension that is narrower than the defined limit is expanded. Exaggeration limit defines the default value for this limit.</p> <p>Exaggeration scaling defines whether you are using Paper or Model as the exaggeration scaling method:</p>

Option	Description
	<ul style="list-style-type: none"> If you select Paper, the exaggeration limit is multiplied by the view scale. If you select Model, and the scale is 1:10, all the dimensions smaller than 10 mm are exaggerated regardless of the drawing scale.
Absolute dimensions	<p>Show zero in absolute dimensions --> Yes shows zero at the zero points in absolute dimensions.</p> <p>Draw absolute dimension values parallel to dimension line --> Yes shows dimensions parallel to dimension lines in absolute dimensions.</p>
Dimensions in tags	<p>Units, Format and Precision define the default unit, format and precision used in dimension tags.</p> <p>Show dimension in middle tag of automatic dimension defines whether you want to create dual dimension tags in assembly, single-part, cast unit, or general arrangement drawings.</p> <p>When Tekla Structures creates the drawing, it adds the lower dimension tag in the selected unit, format and precision.</p>
Add mark to reinforcement	<p>Dimension Marks settings and Tagged Dimension Mark settings define the predefined property files used for dimension marks and tagged dimension marks files.</p>
Dimension line	<p>Dimension line extension length for line arrow defines the length of the line extension for dimensions that have line arrows.</p> <p>Line extensions are not applied to dimensions that have different arrows from line arrows, and certain knock-off dimension types.</p>

Drawing objects page Settings on this page are model-specific.

Option	Description
Edge chamfer	<p>Line color defines the default line color of the edge chamfers in drawings.</p> <p>Line type defines the default line type of the edge chamfers in drawings.</p> <p>These values are overridden by the values set in the Edge Chamfer Properties dialog box.</p>

General page On this page, **Autosave** settings are user-specific. All other settings are model-specific.

Option	Description
Hidden lines	<p>No dotted defines that hidden lines are not dotted.</p> <p>Other parts dotted defines that hidden lines in other parts are dotted.</p> <p>All parts dotted defines that hidden lines in all parts are dotted.</p> <p>Solid bolts defines that the bolts are shown as solid objects.</p> <p>No solid bolts defines that bolts are not shown as solid objects.</p>
Autosave	<p>Autosave interval: Autosave after every xx modeling or editing commands defines how often Tekla Structures automatically saves a model and a drawing.</p> <p>This number represents the number of commands you have given. For example, if you create many objects without interrupting (Esc or Edit --> Interrupt), it counts as one command.</p> <p>Autosave after creating every xx drawings defines the number of drawings after which Tekla Structures automatically saves your work.</p>
Default adaptivity	<p>Off means that adaptivity is not defined.</p> <p>Relative defines that handles retain their relative distances to the nearest part faces in relation to the part's overall size.</p> <p>Fixed defines that handles retain their absolute distances to the nearest part faces.</p> <p>You can also modify the adaptivity settings for each part separately. These modifications override the default settings in the Options dialog box.</p>

Load modeling page Use the settings on the tabs of this page to define the building code and safety factors Tekla Structures uses in load combination.

Settings on this page are model-specific.

Mouse settings page Settings on this page are user-specific.

Option	Description
Display snap symbols	Hides or shows the snap symbols.
Activate snap grid when free snap is on	Activates the snap grid. You can define grid spacing intervals and offsets for the snap grid origin.



Numbering page Settings on this page are model-specific.

Option	Description
Position number separator	Defines the default position number separator. The options are dot (.), comma (,), slash (/), and hyphen (-).

Option	Description
Rebar position number separator	Defines the default reinforcing bar position number separator. The options are dot (.), comma (,), slash (/), and hyphen (-).
Part number type	Defines the default part number type. The options are Part number and Combined assembly / part number .

Orientation marks page

Settings on this page are model-specific.

Option	Description
North direction	<p>Project north (degrees counter clockwise from global x) defines which direction is north in the model. Enter the value in degrees counter-clockwise from the global x axis.</p> 
Part viewing direction	Defines which direction parts are viewed from in drawings.
Beam skew limit Column skew limit	<p>Tekla Structures uses limit angles to determine whether a part is a beam or a column when creating orientation marks. Tekla Structures treats parts outside these limits as braces.</p>  <p>Parts skewed more than 80° are columns. Parts skewed less than 10° are beams.</p>
Preferred location for mark	Defines the location of part marks in drawings, to the left or right end of the part.
Mark always to center of column	<p>This setting only affects columns.</p> <p>Yes places part marks in the center of columns in plan views. To indicate part orientation, include compass direction (Face direction) in the part mark instead.</p> <p>No places part marks on the same flange in general arrangement and assembly drawings.</p>

Units and decimals page

Units and decimals given on the **Modeling** and **Catalogs** tabs affect input. The units and decimals given on the **Analysis results** tab affect the output data.

The settings on the **Modeling** tab affect the data that is used when you are modeling, for example copying, moving, creating grids, creating points, etc. Settings on the **Catalogs** tab affect the data stored in the profile and material catalogs.

Settings on the **Units and decimals** page do not have any effect on drawings or reports, or on the **Inquire** and **Measure** tools.

The number to the left of each option indicates the number of decimals.

The number of decimals affects the input and storage accuracy. Always use a sufficient number of decimals.

Settings on this page are model-specific.

Option	Description
Length	mm, cm, m, in (decimal), ft (decimal), ft-in
Angle	°, rad
Spring constant	kg/m kg/cm kg/mm T/m T/cm T/mm N/m N/cm N/mm daN/m daN/cm daN/mm kN/m kN/cm kN/mm lbf/in lbf/ft

Option	Description
Rot. spring constant	kgm/rad kgm/° Tm/rad Tm/° Nm/rad Nm/° daNm/rad daNm/° kNm/rad kNm/° lbf-in/rad lbf-in/° lbf-ft/rad lbf-ft/° kip-in/rad kip-in/° kip-ft/rad kip-ft/°
Factor	Enter a value using the arrow buttons.
Force	kg T N daN kN lbf kip
Distributed load	kg/m T/m N/m daN/m kN/m lbf/in lbf/ft kip/in kip/ft
Surface load	kg/m ² T/m ² N/m ² daN/m ² kN/m ² psi psf ksi ksf

Option	Description
Moment	kgm Tm Nm daNm kNm lbf-in lbf-ft kip-in kip-ft
Distributed moment	kgm/m Tm/m Nm/m daNm/m kNm/m lbf-ft/ft kip-ft/ft
Temperature	°C, °F, K
Deformation	mm cm m in (decimal) ft (decimal) ft-in
Section dimension	mm cm m in (decimal) ft (decimal) in ft-in
Angle	°, rad
Area	mm ² cm ² m ² in ² ft ²
Section modulus	mm ³ cm ³ m ³ in ³ ft ³
Moment of inertia	mm ⁴ , cm ⁴ , in ⁴

Option	Description
Radius of inertia	mm cm m in (decimal) ft (decimal) ft-in
Torsion constant	mm4, cm4, in4
Warping constant	mm6, cm6, in6
Cover area	m ² /m mm ² /m cm ² /m ft ² /ft in ² /ft in ² /in
Strength	kg/m ² kg/cm ² kg/mm ² T/m ² T/cm ² T/mm ² N/m ² N/cm ² N/mm ² daN/m ² daN/cm ² daN/mm ² kN/m ² kN/cm ² kN/mm ² psi psf ksi ksf

Option	Description
Modulus	kg/m ² kg/cm ² kg/mm ² T/m ² T/cm ² T/mm ² N/m ² N/cm ² N/mm ² daN/m ² daN/cm ² daN/mm ² kN/m ² kN/cm ² kN/mm ² psi psf ksi ksf
Density	kg/m ³ T/m ³ N/m ³ kN/m ³ lbf/ft ³
Weight	kg T N lbf kip
Strain	o/oo, %
Thermal dilat. coeff.	1/°C, 1/°F, 1/K
Ratio	o/oo, %
Volume	mm ³ cm ³ m ³ in ³ ft ³
Length	mm, cm, m, in (decimal), ft (decimal), ft-in
Angle	°, rad

Option	Description
Reinforcement area	mm ² cm ² m ² in ² ft ²
Transverse reinforc.	m ² /m mm ² /m cm ² /m ft ² /ft in ² /ft in ² /in
Weight	kg T N lbf kip
Mass/Length	kg/m T/m N/m daN/m kN/m lbf/ft
Volume	mm ³ cm ³ m ³ in ³ ft ³
Force	kg T N daN kN lbf kip
Distributed load	kg/m T/m N/m daN/m kN/m lbf/in lbf/ft kip/in kip/ft

Option	Description
Surface load	kg/m ² T/m ² N/m ² daN/m ² kN/m ² psi psf ksi ksf
Moment	kgm Tm Nm daNm kNm lbf-in lbf-ft kip-in kip-ft
Temperature	°C, °F, K
Stress	kg/m ² kg/cm ² kg/mm ² T/m ² T/cm ² T/mm ² N/m ² N/cm ² N/mm ² daN/m ² daN/cm ² daN/mm ² kN/m ² kN/cm ² kN/mm ² psi psf ksi ksf
Deformation	mm cm m in (decimal) ft (decimal) ft-in

See also [Detecting clashes](#)

Creating exaggerated dimensions
Automatic drawing-level dimensioning
Adding dual dimensions manually
Adding predefined reinforcement dimensions
Edge chamfers in drawings
Saving a model
Autosaving in multi-user mode
Modifying the shape of a reinforcement using adaptivity
Other snap switches
Defining a snap grid
Load combination properties
Displaying orientation marks (north marks)
Displaying compass direction
Mark location
Setting viewing direction for columns in assembly drawings
Setting viewing direction for beams and bracings in assembly drawings...
[Files storing options and advanced options on page 18](#)

Settings defined by advanced options

Advanced options can be user-, model-, system or role-specific:

- **User-specific advanced options** are saved in your local `options.bin` file, which is by default located in `C:\Users\\AppData\Local\Tekla Structures\<version>\UserSettings`, and work in the specified way in all models that you have. The folder can be changed using the advanced option `XS_USER_SETTINGS_DIRECTORY`. In the **Advanced Options** dialog box, the type is **USER**. Some user-specific advanced options require restarting of Tekla Structures after changing the value.
- **Model-specific advanced options** work in the specified way only in the current model. They are saved to `options_model.db` and `options_drawings.db` under model folder. In the **Advanced Options** dialog box, the type is **MODEL** or **DRAWING**. Some special model-specific options that are not visible in the **Advanced Options** dialog box can be changed from `options.ini` file under the model folder.
- **System-specific advanced options** are general to all sessions of Tekla Structures, and work in the specified way for all users and in all models. In the **Advanced Options** dialog box, the type is **SYSTEM**. A system-specific advanced option can be stored to `options.ini` under model folder by clicking **SYSTEM** next to the option and changing it to **MODEL(SYSTEM)**. Note that the changed value only works for the current

model. A **MODEL(SYSTEM)** advanced option can be changed back to **SYSTEM** by changing it to **SYSTEM**, and in this case it will be removed from the `options.ini` file under model folder. Some system-specific advanced options require restarting of Tekla Structures after changing the value.

The system-specific advanced options are read from environment `.ini` files:

- **Global system settings** are read from common `env_global_default.ini` in `..\ProgramData\Tekla Structures\<version>\environments\common\`. These settings are used in all environments.
- **Environment-specific system settings** are read from `env_<environment>.ini` in your environment folder. They override any settings that are defined on a global level in `env_global_default.ini`.
- **Role-specific system settings** are read from `role_<role>.ini` in environment folder. They override any settings that are defined on a global and environment level in `env_global_default.ini` and `env_<environment>.ini`.
- **Company level system-specific system settings** override all other system-specific advanced options. You can save them in the firm or project folders by setting the folders for the advanced options `XS_FIRM` and `XS_PROJECT`.
- **SYSTEM(ROLE)** options are typically role specific. The settings are read from `.ini` files and are not saved to the databases. When changed or if the type is changed, the option will become model specific and be saved to the databases. **MODEL/DRAWING(ROLE)** options are **SYSTEM(ROLE)** options whose type and/or setting has been changed. The change would be used when you want the **SYSTEM(ROLE)** option to be saved with the model to `options_model.db` and `options_drawings.db` under model folder. These settings can be set back to **SYSTEM(ROLE)**, which will then take into use the default value.

See also `XS_FIRM`

`XS_PROJECT`

[Typical initialization files and their reading order on page 10](#)

List of user-specific advanced options

Tekla Structures saves the settings for the user-specific advanced options in the `options.bin` file, located in the folder `..\Users\<user>\AppData\Local\Tekla Structures\<version>\UserSettings` (Windows 7 and Windows Vista), or in the folder `..\Documents and Settings\<user>\Application Data\Tekla Structures\<version>\UserSettings` (Windows XP). Below is a list of user-specific options:

`RPC_WAIT_TIME`

`TEXT_X_SIZE`

`TEXT_Y_SIZE`

XS_ALWAYS_CONFIRM_SAVE_WHEN_CLOSING_DRAWING
XS_ALWAYS_CONFIRM_SAVE_WHEN_EXIT
XS_AUTOMATIC_NEW_MODEL_NAME
XS_AUTOMATIC_USER_FEEDBACK_SENDING_INTERVAL
XS_AUTOSAVE_DIRECTORY
XS_BACKGROUND_COLOR1
XS_BACKGROUND_COLOR2
XS_BACKGROUND_COLOR3
XS_BACKGROUND_COLOR4
XS_BASICVIEW_HEIGHT
XS_BASICVIEW_POSITION_X
XS_BASICVIEW_POSITION_Y
XS_BASICVIEW_WIDTH
XS_BLACK_DRAWING_BACKGROUND
XS_CHAMFER_DISPLAY_LENGTH_FACTOR
XS_CHANGE_DRAGGED_DIMENSIONS_TO_FIXED
XS_CHANGE_DRAGGED_MARKS_TO_FIXED
XS_CHANGE_DRAGGED_NOTES_TO_FIXED
XS_CHANGE_DRAGGED_TEXTS_TO_FIXED
XS_CHANGE_DRAGGED_VIEWS_TO_FIXED
XS_CHECK_BOLT_EDGE_DISTANCE_ALWAYS
XS_CIS_DEP1_EXPRESS_FILE
XS_CLONING_TEMPLATE_DIRECTORY
XS_COMPONENT_CATALOG_COLLECTION_NAME_LENGTH
XS_COMPONENT_CATALOG_THUMBNAIL_SIZE
XS_CREATE_ALSO_BIG_HTML_REPORT_PICTURES
XS_CREATE_DRAWING_PREVIEW_AUTOMATICALLY
XS_DEFAULT_FONT
XS_DEFAULT_FONT_SIZE
XS_DEFAULT_FONT_SIZE_GRID
XS_DISABLE_ANALYSIS_AND_DESIGN
XS_DISABLE_CIS2
XS_DISABLE_CLASSIFIER_FOR_MODIFIED_PARTS
XS_DISABLE_MASTER_DRAWING_CATALOG
XS_DISABLE_PARTIAL_REFRESH
XS_DISABLE_REBAR_MODELING
XS_DISABLE_TEMPLATE_DOUBLE_CLICK

XS_DISPLAY_DIMENSIONS_WHEN_CREATING_OBJECTS
XS_DISPLAY_DIMENSIONS_WHEN_SELECTING_OBJECTS
XS_DO_NOT_CREATE_ASSEMBLY_DRAWINGS_FOR_CONCRETE_PARTS
XS_DO_NOT_CREATE_ASSEMBLY_DRAWINGS_FOR_LOOSE_PARTS
XS_DO_NOT_CREATE_BOLT_MARKS_IN_ALL_INCLUDED_SINGLE_VIEWS
XS_DO_NOT_CREATE_PART_MARKS_IN_ALL_INCLUDED_SINGLE_VIEWS
XS_DO_NOT_DISPLAY_CHAMFERS
XS_DONT_SHOW_POLYBEAM_MID_EDGES
XS_DRAW_CUT_FACES_WITH_RED_COLOR
XS_DRAWING_ALLOW_SNAPPING_TO_DISTANT_POINTS
XS_DRAWING_CHECK_PARTS_IN_UPDATE
XS_DRAWING_SHEET_HEIGHT
XS_DRAWING_SHEET_POSITION_X
XS_DRAWING_SHEET_POSITION_Y
XS_DRAWING_SHEET_WIDTH
XS_DRAWING_UDAS_MODIFY_ALL_DRAWING_TYPES
XS_DRAWING_VIEW_DIRECTION_MARK_SYMBOL_BACK
XS_DRAWING_VIEW_DIRECTION_MARK_SYMBOL_BOTTOM
XS_DRAWING_VIEW_DIRECTION_MARK_SYMBOL_FRONT
XS_DRAWING_VIEW_DIRECTION_MARK_SYMBOL_TOP
XS_DSTV_DO_NOT_UNFOLD_POLYBEAM_PLATES
XS_DUPLICATE_CHECK_LIMIT_FOR_COPY_AND_MOVE
XS_ENABLE_AUTODRAWINGS_IN_MENU
XS_ENABLE_DOUBLE_BUFFERING_IN_DRAWINGS
XS_ENABLE_POUR_MANAGEMENT
XS_ENABLE_SOLID_ERROR_DIALOG
XS_EXPORT_CODEPAGE
XS_EXPORT_LINE_TYPE_DEFINITION_FILE
XS_EXPORT_TO_MODELSPACE_AND_PAPERSPACE
XS_FAILED_SOLID_COLOR
XS_GRID_COLOR
XS_GRID_COLOR_FOR_WORK_PLANE
XS_GRID_DIMENSION_OVERALL_LENGTH
XS_HANDLE_SCALE
XS_HARD_STAMP_BY_ORIENTATION_MARK
XS_HIDDEN_USE_BOLT_PLANES
XS_HIDE_OTHER_PARTS_IN_ASSEMBLY_AND_CAST_UNIT_VIEWS

XS_HIDE_WORKAREA
XS_HIGHLIGHT_ASSOCIATIVE_DIMENSION_CHANGES
XS_HIGHLIGHT_MARK_CONTENT_CHANGES
XS_HTML_REPORT_LEAVE_INTERMEDIATE_FILES
XS_IMPERIAL_DATE
XS_IMPERIAL_INPUT
XS_IMPERIAL_TIME
XS_IMPORT_MODEL_LOG
XS_INTELLIGENT_MESSAGES_ALLOWED
XS_KEEP_AUTOSAVE_FILES_ON_EXIT_WHEN_NOT_SAVING
XS_KEYIN_ABSOLUTE_PREFIX
XS_KEYIN_DEFAULT_MODE
XS_KEYIN_RELATIVE_PREFIX
XS_MACRO_LOG
XS_MDIBASICVIEWPARENT
XS_MDIVIEWPARENT
XS_MDIZOOMPARENT
XS_MIS_SEQUENCE
XS_MODEL_TEMPLATE_DIRECTORY
XS_NO_AUTO_DISPLAY_VIEWS
XS_NO_CHAMFERS_IN_EXACT_MODE
XS_OBJECT_SELECTION_CONFIRMATION
XS_OPEN_DRAWINGS_MAXIMIZED
XS_PILOTING_EXTENSIONS
XS_PIXEL_TOLERANCE
XS_PLOT_UNPLOT_BUFFER_SIZE
XS_POP_MARK_EDGE_DISTANCE
XS_PRINT_REPORT_FONT
XS_PROFILE_ANALYSIS_CHECK_ALL
XS_PROFILE_ANALYSIS_VALUE_DIFF_LIMIT
XS_PROFILE_DISPLAY_INCH_MARK_AFTER_FRACTIONS_IN_REPORTS
XS_RECREATE_UNMODIFIED_DRAWINGS
XS_REDRAW_VIEWS_AFTER_SELECTED_NUMBERING
XS_REFERENCE_CACHE
XS_REFERENCE_USE_RENDERED_CLIPPING
XS_RENDERED_CURSOR_LINE_WIDTH
XS_RENDERED_FIELD_OF_VIEW

XS_RENDERED_FOG_END_VALUE
XS_RENDERED_FOG_START_VALUE
XS_RUN_AT_STARTUP
XS_SDNF_IMPORT_MIRROR_SWAP_OFFSETS
XS_SHOW_PROGRESS_BAR_FOR_PROJECT_STATUS_VISUALIZATION
XS_SHOW_REVISION_MARK_ON_DRAWING_LIST
XS_SHOW_TEMPLATE_LOG_MESSAGES
XS_SMRT_SEPARATE_MEMORY_POOL_FOR_SOLIDS
XS_SMRT_SOLID_POOL_PAGE_SIZE
XS_SNAPSHOT_DIRECTORY
XS_SOLID_BUFFER_SIZE
XS_THUMBNAIL_FONT
XS_USE_COLOR_DRAWINGS
XS_USE_DRAWING_NAME_AS_PLOT_TITLE
XS_USE_MULTI_NUMBERING_WHEN_COPYING_DRAWING_VIEWS
XS_USE_OBJECT_LOCK_PROTO
XS_USE_SMOOTH_LINES
XS_USE_SOFTWARE_RENDERING
XS_VIEW_DIM_LINE_COLOR
XS_VIEW_DIM_TEXT_COLOR
XS_VIEW_FAST_BOLT_COLOR
XS_VIEW_HEIGHT
XS_VIEW_PART_LABEL_COLOR
XS_VIEW_POSITION_X
XS_VIEW_POSITION_Y
XS_VIEW_WIDTH
XS_VISUALIZE_VIEW_NEIGHBOUR_PART_EXTENSION
XS_VISUALIZE_VIEW_IN_ANOTHER_VIEWS
XS_VISUALIZE_VIEW_IN_FATHER_VIEW_ONLY
XS_ZOOM_STEP_RATIO
XS_ZOOM_STEP_RATIO_IN_MOUSEWHEEL_MODE
XS_ZOOM_STEP_RATIO_IN_SCROLL_MODE

See also [Settings defined by advanced options on page 32](#)

[Changing advanced option settings on page 37](#)

Changing advanced option settings

Use advanced options to configure Tekla Structures to suit the way you work, or to comply with specific project requirements or industry standards.

Change the advanced options only in the **Advanced Options** dialog box. The settings in the **Advanced Options** dialog override the settings in any other initialization file.

To change an advanced option setting:

1. Click **Tools --> Options --> Advanced Options...** to open the **Advanced Options** dialog box.
2. Browse the categories to find the advanced option you want to set.

You can also enter a search term in the **Search** box. To search the search term in all categories, select **In all categories**. You can also use wildcards. For example, to find all advanced options that have the words `anchor` and `filter` and that have any characters between these two words, enter `anchor*filter`.

3. Set the advanced option to the desired value by entering the value or by selecting from the list.
 - You can change the type of the role-specific advanced options from **SYSTEM (ROLE)** to **MODEL (ROLE)** or **DRAWING(ROLE)** and vice versa from the list next to the option type. When you change the option type to **SYSTEM(ROLE)**, the value automatically changes to the default value. When you enter a value for a **SYSTEM (ROLE)** option, it changes to **MODEL (ROLE)** or **DRAWING(ROLE)**.
 - You can change the type of system-specific advanced options from **SYSTEM** to **MODEL(SYSTEM)**, in which case the value is saved in the `options.ini` file in the model folder. If you reset the advanced option back to **SYSTEM**, it will be removed from the `options.ini` file.
 - You can use switches with some advanced options, for example, to define the contents of marks: `%TPL:PROJECT.NUMBER%`.
 - If you need to enter a folder path, enter a backslash at the end of the folder path.
4. Click **Apply** or **OK**.



To create a complete list of advanced options in a text file, click **Write to file**. The list shows the name of the advanced option together with its current value and type.

See also [Settings defined by advanced options on page 32](#)

3.3 Input files

Tekla Structures uses input files to manage dialog boxes and for defining how components work. All input files have the extension `inp`.

Input files that you can use for example for customizing Tekla Structures are listed below.

File	Description
<code>analysis_design_config.inp</code>	Contains settings for analysis and design.
<code>fltprops.inp</code>	Includes materials and dimensions of available flat bars.
<code>objects.inp</code>	Used to manage user-defined attributes.
<code>pop_mark_parts.inp</code>	Contains settings for pop-marking.
<code>privileges.inp</code>	Used to control access rights.
<code>profitab.inp</code>	Contains available parametric profiles.
<code>rebar_config.inp</code>	Contains settings for reinforcement marks.
<code>rebar_schedule_config.inp</code>	Contains internal bending types of reinforcing bars and their mapping to area specific bending codes. Rebar Shape Manager is a more versatile way to define reinforcing bar bending shapes.

See also Analysis model properties
Reinforcement settings for drawings
Reinforcement in templates

Customizing user-defined attributes

Many dialog boxes contain user-defined attributes for various objects, including beams, columns, bolts and drawings. Tekla Structures displays these fields when you click the **User-Defined Attributes...** button. You can use the values of user-defined attributes in reports and drawings.

The definitions of a user-defined attribute are unique, which means that a user-defined attribute cannot have different definitions for different object types, such as beams and columns.

To define new user-defined attributes, create your own `objects.inp` file in the model, project or firm folder.



Do not copy the `objects.inp` file in the `..\environments\common\inp\` folder. Copying the file creates unnecessary duplicates and later `objects.inp` updates made by Tekla can be lost.

Tekla Structures reads the `objects.inp` files in the following order:

1. model folder
2. project folder
3. firm folder
4. system folder
5. `inp` folder

The files are merged so that if there are user-defined attributes in any of the files, they are displayed in the user interface. Tekla Structures merges the files in a way that eliminates duplicate attributes.

If Tekla Structures encounters the same attribute name in different `objects.inp` files, the attribute from the first read `objects.inp` file will be used.

See also [Updating definitions of user-defined attributes in a model on page 40](#)
[The environment database file on page 40](#)
[Objects.inp properties on page 41](#)
[User-defined attributes affecting numbering on page 43](#)
[Example: Creating and updating a user-defined attribute on page 43](#)

The environment database file

To guarantee consistent model behavior when a model is used with different roles, the environment database file (`environment.db`) contains the definitions of the user-defined attributes used in the model.

When you create a new model, Tekla Structures merges the definitions from your `objects.inp` files to the `environment.db` file. Later, when you add **new** user-defined attributes in the `objects.inp` file, the definitions are saved in `environment.db` as you open the model.

You can modify your user-defined attributes in an `objects.inp` file but the **changed** definitions do not come into effect automatically. If there are conflicts, the definitions in `environment.db` win. You need to run the **Diagnose & Change Attribute Definitions** command to see the conflicts between `environment.db` and `objects.inp`, and select the attribute definitions that you want to update.

See also [Customizing user-defined attributes on page 39](#)
[Updating definitions of user-defined attributes in a model on page 40](#)
[Example: Creating and updating a user-defined attribute on page 43](#)

Updating definitions of user-defined attributes in a model

When you have changed definitions of a user-defined attribute by modifying the `objects.inp` file, you need to update the definitions in the model.

To update the definitions of user-defined attributes after you have modified the `objects.inp` file:

1. Open the model.
2. Click **Tools --> Diagnose & Repair Model --> Diagnose & Change Attribute Definitions**.

The **Diagnose & Change Attribute Definitions** dialog box opens.

3. Select an attribute from the list on left side to see the comparison of current definitions and `objects.inp` definitions.
4. Select the definitions you want to update in the **Object classes with Objects.inp differences compared to current settings** list.
5. Click **Change current settings to selected Objects.inp settings**.

See also [Customizing user-defined attributes on page 39](#)

[The environment database file on page 40](#)

[Objects.inp properties on page 41](#)

[Example: Creating and updating a user-defined attribute on page 43](#)

Objects.inp properties

The example below shows the main properties of `objects.inp`.

```
attribute("MY_INFO_1", "My Info 1", string, "%s", no, none, "0.0", "0.0")
{
    value("", 0)
```

Property	In the example	Description
attribute or unique_attribute	attribute	attribute is a regular attribute, which is copied with other part properties. unique_attribute is a non-copyable attribute. The value of the attribute is never copied to another part. For example part checking status attributes usually cannot be copied.
attribute_name	MY_INFO_1	Attribute name, used to find the attribute value. Ensure that Tekla Structures does not already use the attribute name you use. Consider using a prefix that ensures the name is unique, for example, your initials, or an abbreviation of your company name.

Property	In the example	Description
		<p>The attribute name is case-sensitive. Do not use spaces or reserved characters in attribute names. The maximum length of the name can be 19 characters.</p> <p>To include the attribute in a report or template, add the name of the attribute to your layout in the Template Editor. When you run a report or create a drawing, Tekla Structures displays the current value of the attribute.</p>
label_text	My Info 1	<p>Label that Tekla Structures displays in the dialog box.</p> <p>Some default attributes have prompts like <code>j_comment</code>, meaning that the prompt comes from the <code>joints.aif</code> message file.</p>
value_type	string	<p>integer or float for numbers</p> <p>string for text</p> <p><code>string_not_modifiable</code> for text whose modification is prevented. A field with the <code>string_not_modifiable</code> property is always displayed as dimmed and it cannot be switched on or off. The value in the field is not saved when clicking the Apply button or modified when clicking the Modify button.</p> <p><code>option</code> for lists</p> <p><code>date</code> for date with small calendar</p> <p><code>date_time_min</code> for date and time [12:00] with small calendar</p> <p><code>date_time_sec</code> for date and time [12:00:00] with small calendar</p>
field_format	%s	<p>Definition of the field format in the dialog box</p> <ul style="list-style-type: none"> • %s for strings • %d for numbers
special_flag	no	<p>no or yes</p> <p>For parts: consider in numbering</p> <p>For drawings: display the attribute value in drawing list</p> <p>For other elements: no effect</p>
check_switch	none	<p>none</p> <p>This option is not used.</p>

Property	In the example	Description
attribute_value_max	0.0	0.0 This option is not used.
attribute_value_min	0.0	0.0 This option is not used.

See also [User-defined attributes affecting numbering on page 43](#)

User-defined attributes affecting numbering

You can set whether the user-defined attribute affects numbering or not.

If you want Tekla Structures to consider the user-defined attribute when numbering, set the `special_tag` option to `yes` in the `Part attributes` section of `objects.inp`. Tekla Structures assigns different numbers to parts that are otherwise identical but have different user-defined attributes.



Only user-defined attributes of parts affect numbering. User-defined attributes of other objects, such as phases, projects and drawings do not affect numbering.

If you want Tekla Structures to ignore the user-defined attribute when numbering, set the `special_tag` option to `no` in `objects.inp`.

See also [Objects.inp properties on page 41](#)

Example: Creating and updating a user-defined attribute

This example shows how to create your own user-defined attribute and update the model to use the changed attribute definition.

To create and update a user-defined attribute:

Creating a new user-defined attribute

1. Create a new model and save it.
The user-defined attributes in the model are merged from `objects.inp` files and Tekla Structures saves the attribute definitions in the `environment.db` file in the model folder.
2. Close the model.
3. Create an input file called `objects.inp` in the model folder by using a standard text editor.
4. Enter the following information in `objects.inp`.

```

/*****
/* Part attributes */
/*****
part(0, "part")
{
    /* User defined tab page: */
    tab_page("My UDA tab")
    {
        /* User defined attribute: */
        attribute("My UDA", "My UDA", string, "%s", no, none, "0,0", "0,0")
        {
            value("", 0)
        }
    }
    tab_page("My UDA tab", "My UDA tab", 19)
    modify(1)
}

/*****
/* Column attributes */
/*****
column(0, "j_column")
{
    /* Reference to the user defined tab page that is defined above in */
    /* the part() section: */
    tab_page("My UDA tab", "My UDA tab", 19)
    modify(1)
}

```



If you want to create a user-defined attribute that also affects numbering, set the `special_flag` property of the attribute to `yes` (it is `no` in the example below). Also, just like in the example above, the definition of the `tab_page` must be in the `part` section, and the `column` (`beam`, etc.) section must have only a reference to it.

5. Save `objects.inp`.

Testing the user-defined attribute

1. Open the model.
2. Create a steel column.
3. Double-click the steel column to open its properties dialog box.
4. Click **User-defined attributes**.
5. Go to **My UDA tab**.



6. Enter a value in the **My UDA** box.

7. Click **Modify**.
8. Copy the steel column.
9. Check the **My UDA** box of the new steel column.
The attribute value was also copied.
10. Close the model.

Modifying the user-defined attribute

1. Open the `objects.inp` file in the model folder by using a standard text editor.
2. Enter `unique_` before the user-defined attribute.

```

/*****
/* User-defined attributes */
*****/

part(0,"Part")
{
/* Common tab pages for part attributes */
tab_page("My UDA tab")
{
unique_attribute("My UDA", "My UDA", string, "%s", no, none, "0,0", "0,0")
{
value("", 0)
}
}
}
tab_page("My UDA tab","My UDA tab",19)
modify(1)
}
/*****
/* Column attributes */
*****/
column(0,"j_column")
{
tab_page("My UDA tab","My UDA tab",19)
modify(1)
}
}

```

This makes the user-defined attribute unique, meaning that the value of the user-defined attribute will not be copied to another part.

3. Save `objects.inp`.

Testing the unique user-defined attribute

1. Open the model.
2. Enter a value in the **My UDA** box for a steel column and click **Modify**.
3. Copy the steel column.
4. Check the **My UDA** box of the new column.
5. The value was copied, so the user-defined attribute in the model is not unique. There is a conflict between the `environment.db` and `objects.inp` definitions.

Updating the definitions of user-defined attributes

1. Click **Tools --> Diagnose & Repair Model --> Diagnose & Change Attribute Definitions**.

The **Diagnose & Change Attribute Definitions** dialog box opens.

2. Select **My UDA** in the **Attribute** area on the left.

You can see that **My UDA** is not unique in the current setting, but it is set to unique in `objects.inp`.

Object classes with Objects.inp differences compared to current settings

Current settings	Object class names	Objects.inp settings
unique=no	part column	unique=yes

3. Select the definition in the area on the right.
4. Click **Change current settings to selected Objects.inp settings**.

Now the definition of the user-defined attribute is updated in the model.

If you now copy a steel column that has a value for **My UDA**, the value is not copied to the new column.

See also [Updating definitions of user-defined attributes in a model on page 40](#)

[Customizing user-defined attributes on page 39](#)

[Objects.inp properties on page 41](#)

[User-defined attributes affecting numbering on page 43](#)

Showing plates as flat bars in drawings and reports

Tekla Structures can show plates as the equivalent flat bars for manufacturing. Tekla Structures displays the plates as flat bars in reports and drawings.

To show plates as flat bars:

1. Set the advanced option `XS_USE_FLAT_DESIGNATION` to `TRUE`.
2. Indicate the prefix you want to use for flat bars using the advanced option `XS_FLAT_PREFIX`.
For example, `XS_FLAT_PREFIX=FLAT`.
3. Set other platework-related advanced options as required.
4. Define materials, thickness, and width of available flat bars in the `Fltprops.inp` file.



- To prevent Tekla Structures from displaying the profile in metric units in the US Imperial version, add the flat bar prefix to the `profitab.inp` file as a parametric profile.
- See also page **Platework** in the **Advanced Options** dialog box for information about advanced options related to platework.

See also [Defining flat bar sizes with Fltprops.inp on page 46](#)

Defining flat bar sizes with Fltprops.inp

Use the `..\environments\your_environment\profil\Fltprops.inp` file to define flat bar thickness, width and material.



Copy the `Fltprops.inp` file to a model, project or firm folder and then modify the file in the new location as required.

The first row in the file contains flat bar material definitions (enclosed in quotes `" "`) followed by plate thicknesses. If you do not define a material, you can use all materials for all flat bars. The following rows define the widths of available flat bars.

The units are millimeters.

Example `Fltprops.inp` contains the following data:

```
5, 6, "S235", 8, 10, "S275J0", 10, 15
40, 45
50, 55
60, 65
70, 75
100, 110
200, 220
```

With the above data, Tekla Structures displays the following plates as flat bars:

Plate	Material
5x40, 5x45, 6x50, 6x55	All materials
8x60, 8x65, 10x70, 10x75	S235
10x100, 10x110, 15x200, 15x220	S275J0

The flat bars get the prefix that is set in the `XS_FLAT_PREFIX` advanced option.

See also [Showing plates as flat bars in drawings and reports on page 46](#)

Defining unfolding parameters

The unfolding parameters define the location of the neutral axis when a profile is unfolded. The neutral axis is a line which runs along the length of a profile where stress and strain are equal to zero. Tekla Structures uses these parameters to create NC files and to display unfolded profiles in single-part drawings.

To define unfolding parameters, modify the `unfold_corner_ratios.inp` file located in the system folder using a standard text editor. You can copy the `unfold_corner_ratios.inp` file to a model, project or firm folder and then modify the file in the new location as required. Tekla Structures searches for this file in the default search order.



The settings in `unfold_corner_ratios.inp` have no effect if the advanced option `XS_USE_OLD_POLYBEAM_LENGTH_CALCULATION` is set.

See also [Folder search order on page 84](#)
[Unfolding parameter properties on page 48](#)

Unfolding parameter properties

See below for an example of unfolding parameters in `unfold_corner_ratios.inp` and the descriptions of the parameters.

```
1 HE300A S235JR 0 180 2 0 1000 .7
```

Property	In the example	Description
Type	1	1 is polybeams 2 is plates modeled as polybeams (for example, PLT) 3 is for parts which are not unfolded and follow the old polybeam calculation (for example, the line 3 L* * disables unfolding of L profiles)
Profile	HE300A	You can also use wildcards with profile, for example, HE300*.
Material	S235JR	You can also use wildcards with material, for example, S235*.
Rotation / thickness min	0	For polybeams: the minimum angle when the profile is rotated around its longitudinal axis For plates: the minimum thickness of plate
Rotation / thickness max	180	For polybeams: the maximum angle when the profile is rotated around its longitudinal axis For plates: the maximum thickness of plate
Flag	2	This property defines what kind of parts are affected by the next two properties. 1 is sharp folds. Only polybeams with straight chamfers are affected. 2 is curved bends. Only polybeams with curved chamfers are affected.

Property	In the example	Description
Angle / radius min	0	For sharp folds: the minimum angle For curved bends: the minimum radius
Angle / radius max	1000	For sharp folds: the maximum angle For curved bends: the maximum radius
Ratio	.7	Defines how much the profile stretches or shrinks when unfolded. Ratio = (1 - the relative location of the neutral axis). If only the inner surface of the profile shrinks, the ratio is 1. If only the outer surface of the profile stretches, the ratio is 0. By default, the ratio is 0.5 for length calculation and 0.0 for bending radius calculation. Tekla Structures applies the unfolding ratio if the profile properties are within the range indicated by the minimum and maximum values.



To define the rotation angle, set the work plane by the first three points of the polybeam. Set the rotation angle in the **Rotation** box in the **Beam Properties** dialog box.

See also [Defining unfolding parameters on page 47](#)

3.4 Data files

Data files contain information used by certain components, for example.



These files affect the operation of components. Do not modify the files listed here unless you are an administrator.

File	Description
joints.dat	Contains data used in Handrailing (1024) and Stanchions (S76) components. Used in the Stanchion connection type option.
railings.dat	Contains data used in Handrailing (1024) . Used in the Stanchion connection type option.

File	Description
steps.dat	Contains the data for Stairs (S82) and Stairs (S71) . Used in the Step profile and Catalogue step options.
std_flange_plates.dat	Contains data for Tapered column (S99) . Used in the options: <ul style="list-style-type: none"> • Outer flange profile • Inner flange profile • Top plate profile
std_stiffener_plates.dat	Contains data used in Tapered column (S99) . Used in the Horizontal stiffener profile box.
marketsize.dat	Contains available market sizes for certain material grade. Can be used with <code>fMarketSize()</code> function in the custom component editor.
import_macro_data_types.dat	Contains the user-defined attributes that you can include in an input file in attribute import.

See also [Defining flat bar sizes with Fltprops.inp on page 46](#)

3.5 Message files

Tekla Structures uses the information in the message files to display messages in the user interface. Message files include, for example, texts used in dialog boxes.

Message files are located in the folder `..\Tekla Structures\<<version>\messages` (message files with the `.ail` extension) and in the folder `..\Tekla Structures\<<version>\messages\DotAppsStrings` (message files with the `.xml` extension). The files include texts in languages in which the Tekla Structures user interface is available.

See also [Customizing message files on page 50](#)

[Example: Modifying a message file on page 51](#)

Customizing message files

You can customize the messages that Tekla Structures displays in the user interface.

To customize messages:

1. Do one of the following:

- To modify an .ail message file, go to the ..\Tekla Structures \<version>\messages folder.
 - To modify an .xml message file, go to the ..\Tekla Structures \<version>\messages\DotAppsStrings folder.
2. Open the message file you want to customize using a standard text editor.
 3. Modify the message as required.
 4. Save the message file.

See also [Example: Modifying a message file on page 51](#)

Example: Modifying a message file

In this example, you will modify a message that Tekla Structures uses for near side plates in drawings. You want Tekla Structures to display (NS) instead of (N/S).

To modify the message:

1. Go to the ..\Tekla Structures\<version>\messages folder.
2. Open `by_number.ail` using a standard text editor.

The `by_number.ail` file contains both prompts and default texts that Tekla Structures uses in drawings.

3. Browse to the following section:

```
string by_number_msg_no_675 {
...
entry = ("enu", "(N/S)");
};
```


4. Change (N/S) to (NS) in the entry row.
5. Save and close the file.

See also [Message files on page 50](#)

3.6 Standard files

Standard files are property files that Tekla Structures uses by default.

These properties are displayed in the dialog boxes of different objects such as beams, columns or plates, when you select the **standard** option in the list next to the **Load** button, and click the **Load** button.



Standard files are stored in the `..\TeklaStructuresModels\<model_name>\attributes` folder. They are named `standard.*` where the symbol `*` is the file name extension. For example, `standard.clm` file is used for column properties.

To save a set of standard files in the model folder, click **Tools --> Defaults --> Save Defaults**.

See also [Settings in the Options dialog box on page 19](#)

List of standard files saved with Save defaults command

Tekla Structures saves a set of standard files in the `attributes` folder in the current model folder when you click **Tools --> Defaults --> Save Defaults**.

You can copy these standard files to the project or firm folders for future use, to set up Tekla Structures to suit the way you work.

File	Dialog box
<code>standard.cpl</code>	Contour Plate Properties
<code>standard.fpl</code>	Folded Plate Properties
<code>standard.prt</code>	Beam Properties
<code>standard.clm</code>	Column Properties
<code>standard.crs</code>	Orthogonal Beam Properties
<code>standard.dia</code>	Twin Profile Properties
<code>standard.scr</code>	Bolt Properties
<code>standard.wld</code>	Weld Properties
<code>standard.prf</code>	Project properties
<code>standard.ler</code>	Layer Properties
<code>standard.fms</code>	Plotting Frames
<code>standard.num</code>	Numbering Setup
<code>standard.mvi</code>	Model View Properties

See also [Project and firm folders on page 86](#)

3.7 Properties files

Tekla Structures stores a number of files, all of which contain object properties, in the current model folder. Tekla Structures creates these properties files when you click **Save** or **Save as** in dialog boxes.

Example You change the standard column properties to create a new type of column you call `custom1`. When you click **Save as**, Tekla Structures creates the file `custom1.clm` in the current model folder.

See also

3.8 Catalog files

Tekla Structures uses ASCII and binary files to manage profile, material, reinforcing bar, bolt and bolt assembly catalogs.

Each environment has its own folder, where the files related to different catalogs are stored. For example, `..\environments\uk\profil\` contains the files for managing catalog files used in the United Kingdom.

The following table lists files and file types related to catalogs.

File type	File name	Used for	Located in
.inp	profitab.inp	Defines the names that you can use for parametric profiles.	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\profil< td=""> </version>\environments\<environment>\profil<>
	rebar_database.inp	Contains details of the reinforcement used in concrete structures. Includes both the standard bending radii and the standard hook dimensions.	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\profil< td=""> </version>\environments\<environment>\profil<>
	mesh_database.inp	Contains details of the reinforcement meshes used in concrete structures.	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\profil< td=""> </version>\environments\<environment>\profil<>
.cnv	matexp_<software>.cnv	Contains information to convert material names when transferring model information using links. For example, converts S235JR to FE360B for DSTV.	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\profil< td=""> </version>\environments\<environment>\profil<>
	prfexp_<software>.cnv	Contains information to convert profile names when transferring model information using links. For example,	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\profil< td=""> </version>\environments\<environment>\profil<>

File type	File name	Used for	Located in
		converts converts HEA100 to HE100A for DSTV.	
.clb	For example, RU_CF.clb	Contains the definitions of parametric profiles used in profitab.inp.	..\ProgramData\Tekla Structures\ <version>\environments\common\inp< td=""> </version>\environments\common\inp<>
.lis	You can define the file name while exporting.	Created when you export bolt, profile and material catalogs.	You can define the folder where to export the files.
.db	assdb.db	The bolt assembly catalog.	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\profil< td=""> </version>\environments\<environment>\profil<>
	screwdb.db	The bolt catalog.	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\profil< td=""> </version>\environments\<environment>\profil<>
.bin	profdb.bin	The profile catalog.	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\profil< td=""> </version>\environments\<environment>\profil<>
	matdb.bin	The material catalog.	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\profil< td=""> </version>\environments\<environment>\profil<>

See also

3.9 Font files

You can define the location of font files with the advanced option `DXK_FONTPATH` in the `teklastructures.ini` or your environment initialization file. For example, you can use fonts available in the folder `..\ProgramData\Tekla Structures\. This folder includes the following fonts:`

Font	Font type
fixfont.fon	Tekla Structures graphic font
romco.fon	Tekla Structures graphic font
romsim.fon	Tekla Structures graphic font
romsim8.fon	Tekla Structures graphic font

Font	Font type
GOST 2.304-81 type A.ttf	True Type font (Cyrillic)
GOST 2.304-81 type B.ttf	True Type font (Cyrillic)

Fonts are converted using font conversion files available in the same folder:

File	Description
template_fonts.cnv	Used to map Tekla Structures fonts to Windows fonts.
dxfl_fonts.cnv	Used in exporting drawings.

See also

[Initialization files on page 10](#)

3.10 Symbol files

Symbols are used for example in various places in drawings, for example, as separate objects, and in marks.

You can create symbols with Symbol Editor. In this case, the file name extension is `.sym`.

You can also use symbols of `.dwg` format.

Tekla Structures symbol files are by default located in the folder `..\environments\common\symbols`.

See also

3.11 Files related to templates, reports and drawings

Tekla Structures has several files that relate to templates, reports, drawings and printing.

File or file type	Description	Location
rpt	Report templates created with the Template Editor	<code>..\environments\<your_environment>\system\</code> and its role-specific sub-folders
tpl	Drawing templates created with the Template Editor	<code>..\environments\<your_environment>\template</code>
lay	Layout definitions created with the Drawings & Reports --> Drawing Settings --> Drawing Layout... command.	<code>..\environments\<your_environment>\system\</code> and its role-specific sub-folders

File or file type	Description	Location
plotdev.bin	Printer device definitions created with the File --> Print... --> Printer Catalog... command.	..\environments \<your_environment> \system
xdproc	Master Drawing Catalog rule set	...\environments \<your_environment> \system\ and its role-specific sub-folders
xdproc.master	Master Drawing Catalog master drawing file	...\environments \<your_environment> \system\ and its role-specific sub-folders
xdproc.master.png	Master Drawing Catalog sample (preview) image files	...\environments \<your_environment> \system\ and its role-specific sub-folders
xdproc.png	Master Drawing Catalog thumbnail image files	...\environments \<your_environment> \system\ and its role-specific sub-folders

See also

3.12 Image files

Tekla Structures uses image files in several places:

- In templates in drawings
- In drawing snapshots
- In component dialog boxes and thumbnails
- In drawing line types
- In the surface treatment dialog box
- In the **Master Drawing Catalog** for thumbnails and sample images
- In profile properties dialog boxes

The following image file formats are supported in Tekla Structures:

- In templates: bmp, gif, grd, jpg, ppm, pgm, rle, tiff and xkrl
- In drawing snapshots, and int thumbnail and sample images for the **Master Drawing Catalog**: png
- Other situations: bmp

- See also** Adding images in a template
 Creating and viewing drawing snapshots
 Adding sample and thumbnail images to master drawings
 Defining customized line types

3.13 Log files

Tekla Structures writes information to log files when you, for example, number a model or save a model.



All log files are located in the current model folder.

File	Description
analysis.log	Tekla Structures stores information in this file when you run the analysis. The file also contains information on the errors that occurred during load distribution.
check_database.log	Tekla Structures stores information in this file when you run the Tools --> Diagnose & Repair --> Repair Model command.
ClashCheck.log	Contains clashes found in the most recent clash check.
conflict.log	Contains conflicts that have occurred in the multi-user mode when more than a one user has modified an object.
drawing_cloning.log	Contains information on cloned drawings.
drawing_history.log	Contains information on drawing history. Use the advanced option <code>XS_DRAWING_HISTORY_LOG_TYPE</code> to define the contents of the file.
dstv_nc.log	Each time you create NC files, Tekla Structures stores information in this file about the processed assemblies.
filetranerror.log	Used only for cold rolled components, such as Albion, Ayrshire, and Hispan. If the File Transfer components do not work as expected, Tekla Structures stores error messages in this file.
numbering.history	Contains full details of each numbering session carried out on the model. Each session is in a different block of the file.
save_history.log	Tekla Structures stores information in this file each time you save a model.
TeklaStructures.log	Contains information on the entire Tekla Structures session from opening the model to closing it. The file contains, for example, errors and information on which catalogs were used.

File	Description
wizard.log	Tekla Structures stores information in this file when you run a drawing rule set (wizard) file. The file contains, for example, errors and number of drawings created.

See also [Viewing a log file on page 58](#)

XS_DRAWING_HISTORY_LOG_TYPE

XS_CNC_CUT_PLANE_HEIGHT

XS_LOG_FILE_NAME

Viewing a log file

To view a log file:

1. Open the model whose log history you want view.
2. Click **Tools** --> **Display Log File** and select a log file you want to examine.

The options are:

- Session history log (TeklaStructures.log)
- Numbering history log (numbering.history)
- Drawing history log (drawing_history.log)
- Saving history log (save_history.log)
- Clash Check history log (ClashCheck.log)
- Analysis history log (analysis.log)



If you want to view the log files in a viewer that has been associated with the file type, for example, in Microsoft Notepad, select **Tools** --> **Display Log File** --> **With Associated Viewer** .

Alternatively, if you want to view the log files on a toolbar at the bottom of the Tekla Structures window, select **Tools** --> **Toolbars** --> **Message Panel** .

See also [Log files on page 57](#)

[The numbering.history log file on page 59](#)

Viewing parts listed in a log file

The parts that are listed in a log file can be viewed in the model.

To view parts listed in a log file:

1. Click **Tools** --> **Display Log File** .
2. Select a log file you want to examine.
3. In the log file, select a row which contains a part or an assembly.

Parts and assemblies have the prefix `id`.

Tekla Structures highlights the part in the model.

If there are several parts or assemblies on a row and you select that row, Tekla Structures highlights all the parts in the model. You can also select parts on different rows.



You can access a part's or an assembly's pop-up menu from the log file by right-clicking a row that contains a part or an assembly. Tekla Structures displays the same pop-up menu as when you right-click a part or an assembly in the model.

See also [Log files on page 57](#)

The numbering.history log file

The `numbering.history` log file contains full details of each numbering session carried out on the model. Each numbering session is in a different block of the file.



If you remove or delete the `numbering.history` log file, Tekla Structures generates a new file with the same name next time when you run numbering. The new file does not contain a history of previous numbering sessions.

Example Below is an example of the contents of a `numbering.history` log file.

```
① *** Numbering (haka): Thu Jun 14 13:08:08 2012
② Modified numbering
③ Compare modified to old parts
④ Compare new to old parts
④ Check for standard parts
  Use old numbers
⑤ Tolerance: 1.000000
  SteelTolerance: 1.000000
  ConcreteTolerance: 2.000000
  RebarTolerance: 2.000000
⑥ Part      guid: ID510F595D-0000-0017-3133-353939383237  series:Concrete_C-1/1  Concrete_C-1/0 -> Concrete_C-1/1
  Assembly guid: ID510F595D-0000-0016-3133-353939383237  series:C/1  C/0 -> C/1
  *** Operation finished Thu Jun 14 13:08:08 2012
```

①

User name, date and time of the numbering.


<p>②</p>	<p>Numbering method.</p> <ul style="list-style-type: none"> • Modified numbering is displayed when you run the Number Modified Objects command. • Modified numbering for selected series is displayed when you run the Number Series of Selected Objects command. • Diagnose & Repair Numbering: All is displayed when you run the Diagnose & Repair Numbering: All command. • Diagnose & Repair Numbering: Series of selected objects is displayed when you run the Diagnose & Repair Numbering: Series of Selected Objects command. • Renumber all is displayed when you select the Renumber all option in the Numbering Setup dialog box.
<p>③</p>	<p>Some Compare options set in the Numbering Setup dialog box are displayed in the <code>numbering.history</code> log file only if they are set differently than the default value:</p> <ul style="list-style-type: none"> • Compare modified to old parts • Compare new to old part • No holes comparing • No part name comparing • Beam orientation • Column orientation <p>Some Compare options are not displayed at all:</p> <ul style="list-style-type: none"> • Reinforcing bars • Embedded objects • Surface treatment
<p>④</p>	<p>Numbering options.</p> <ul style="list-style-type: none"> • Use old numbers is displayed only when you have selected the Re-use old numbers option in the Numbering Setup dialog box. • Check for standard parts is displayed only when you have selected the Check for standard parts option in the Numbering Setup dialog box.
<p>⑤</p>	<p>Tolerances are set in the Numbering Setup dialog box.</p>
<p>⑥</p>	<p>Changes in the position numbers and in the numbering series during one numbering session.</p>
	<p>In addition:</p> <p>If a numbering series overlaps another, the errors are written to the log file.</p>

See also [Numbering series in the numbering.history log file on page 61](#)

Numbering series in the numbering.history log file

Tekla Structures lists information on the numbered parts and assemblies in the `numbering.history` log file.

Example 1 The `numbering.history` log after one concrete beam **B/20** has been created and numbered:




```

① Part      guid: ID510F595D-0000-0030-3133-353939383335  series:Concrete_B-20/1  Concrete_B-20/0 -> Concrete_B-20/1
② Assembly guid: ID510F595D-0000-002F-3133-353939383335  series:B/20  B/0 -> B/20
    
```

1	<p>Part position number.</p> <ul style="list-style-type: none"> The part with the GUID ID510F595D-0000-0030-3133-353939383335 is a part of the numbering series Concrete_B-20/1. The part becomes the first part in the numbering series: Concrete_B-20/0 -> Concrete_B-20/1.
2	<p>Assembly position number.</p> <ul style="list-style-type: none"> The assembly ID of the part is ID510F595D-0000-002F-3133-353939383335. The part belongs to the B/20 assembly numbering series, which is also the cast unit numbering series. The part gets the assembly position number: B/20: B/0 -> B/20.

Example 2 The `numbering.history` log after another concrete beam **B/21** has been created and numbered:



① Part guid: ID510F595D-0000-0030-3133-353939383335 series:Concrete_B-20/1 Concrete_B-20/0 -> Concrete_B-20/2
 ② Assembly guid: ID510F595D-0000-002F-3133-353939383335 series:B/20 B/0 -> B/21

1	<p>Part position number of the new part.</p> <ul style="list-style-type: none"> The part with the ID ID510F595D-0000-0030-3133-353939383335 is part of the numbering series Concrete_B-20/1. The part becomes the second part in the numbering series: Concrete_B-20/0 -> Concrete_B-20/2.
2	<p>Assembly position number.</p> <ul style="list-style-type: none"> The assembly ID of the part is ID510F595D-0000-002F-3133-353939383335. The part belongs to the B/20 assembly numbering series, which is also the cast unit numbering series. The part gets the assembly position number: B/20 B/0 -> B/21.

See also [The numbering.history log file on page 59](#)

[Viewing parts listed in a log file on page 58](#)

3.14 Model folder files and file name extensions

The following table lists the files and file name extensions in use in Tekla Structures and located in model folder.

File or file name extension	Description	For more information
Files in the Tekla Structures model folder:		
*.db1	The model database	
*.db2	Numbering database	
environment.db	Database for user-defined attribute definitions	

File or file name extension	Description	For more information
xslib.db1	Contains information on user-defined connections and details, and default component descriptions.	
*.idrm	Mapping file, which handles IDs. Do not modify.	
xslib.db2	Contains numbering information.	Numbering the model
options_model.db and options_drawings.db	Contain values for model-specific options from the Options dialog box and values for model-specific advanced options from the Advanced Options dialog box. When a model is created, Tekla Structures reads model-specific options and advanced options values from the <code>standard.opt</code> file and <code>.ini</code> files in the environment folders and saves them in these two databases.	Settings in the Options dialog box on page 19
xldb.xs	File used for displaying the name of the model in the Open dialog box.	Opening a model
xs_user.<user name>	Contains interface settings specified by the user. Each time a model is saved, an <code>xs_user.<user name></code> file is created or updated. These settings are user specific. If the <code>xs_user.<user name></code> settings are not found in the model folder when you open the model, Tekla Structures searches for the <code>xs_user.default</code> file from the following path: <code>model</code> , <code>model/attributes</code> , <code>project</code> , <code>firm</code> , <code>system</code> . If this file is not found, Tekla Structures default settings will be used. The file contains settings for many of the switches on the Tools --> Options menu and the settings for the icons on the Selecting and Snapping toolbars.	
save_history.log	Tekla Structures stores the information in this file each time the model is saved. The file includes the saving time, date and information on any conflicts during saving.	Saving a model
notification_report.xsr	File used for displaying a notification report of assignments when you open a model.	XS_SHOW_NOTIFICATION_REPORT
TeklaStructuresModel.xml	Contains information on the Tekla Structures session, for example on opening, closing and what catalogs are being used.	
dotlog.txt	A log file that contains information on Tekla Open API application use.	Tekla Open API on page 8

File or file name extension	Description	For more information
*.locked	A temporary file that locks the model folder files to prevent modifications while the model is in use.	
*.bak	A backup copy of the model database.	
assert.txt	A log file that contains information on assertion errors.	
ClashCheck.txt	A log file that contains information on clashes found in the most recent clash check and the date and time of the clash check.	Detecting clashes
ClashCheck.history	A file that contains information on all clashes found in all clash checks and the dates and times of the clash checks.	
wizard.txt	Tekla Structures stores information in this file when you run a drawing rule set (wizard) file. The file contains, for example, errors, number of drawings created, and information on which commands were used.	
*.lis	Different catalogs can be exported from and imported to different Tekla Structures models as *.lis files. These include profile, material and bolt catalogs.	Importing a bolt catalog Importing a material catalog Importing profile catalog items Exporting a bolt catalog Exporting a material catalog Exporting a profile catalog
*.tsc	Shapes can be exported from and imported to different Tekla Structures models as *.tsc files.	Importing a shape Exporting a shape
.This_is_multiuser_model	Contains information about the PC running the Tekla Structures multi-user server. Do not alter or delete this file in normal circumstances. If you move a model to a different server, you should delete this file. Tekla Structures generates a new file with the same name.	Installing Tekla Structures multi-user server as a service
ComponentCatalog.txt	Includes the default settings of the search view and any keywords you save in the component catalog.	Component Catalog

File or file name extension	Description	For more information
ModelBasicComponent s.txt	Lists the basic components available.	Component Catalog
Worktypes.xml	Lists available task types. Created when you start the Task Manager.	Defining a task type
WorkTypeProperties.xml	Lists allowed property types and their units.	
.tmp	A file used to store temporary data.	
.cnv	A file used to map Tekla Structures profile and material names with names used in other software.	Conversion files
Files in the analysis model folder:		
*.ifc	The analysis model exported in IFC format.	Analysis model properties
*.stp	The analysis model exported in CIS/2 format.	
*.map	A file used for debugging analysis models.	
analysis_results.db5	Database for analysis load combination results.	Saving analysis results
*.db6	Analysis model database.	Analysis model properties
Files in the \screenshots folder:		
*.png	Screenshot taken in Tekla Structures.	Taking a screenshot
Files in the \attributes folder:		
*.rop	Reference object user-defined attribute properties	Reference model objects
*.rop.more	Reference object properties	
*.m10000017	Fabtrol XML import properties	Fabtrol XML
*.m10000015	Import attribute properties	Attribute import
*.ncf	NC file properties	NC files
*.ExportIFC.MainDialog	IFC export properties	IFC export
*.m440000004	3D DWG/DXF export properties	DWG and DXF
*.m440000003	3D DGN export properties	Exporting to 3D DGN files

File or file name extension	Description	For more information
*.m1000004	FEM export properties	FEM
*.m10000011	CIS analysis model export properties	CIS and CIMSteel
*.m10000026	CIS manufacturing model export properties	CIS and CIMSteel
*.m1000007	CAD export properties	Exporting to CAD
*.m10000016	Cover sheet export properties	
*.SObjGrp	Object group selection filter properties	Filtering objects using a selection filter
*.grd	Grid properties	Grid properties
*.grd.more	Grid user-defined attribute properties	
*.grdp	Grid line properties	Grid line properties
*.grdp.more	Grid line user-defined attribute properties	
*.mvi	<p>Model view properties that you have saved for the model.</p> <p>Default 3D, part, component, custom component, assembly, and cast unit view settings files need to be saved with names used in common environment:</p> <p>3D view: basic_view</p> <p>3D part view: part_basic_view</p> <p>Part front view: part_front_view</p> <p>Part top view: part_top_view</p> <p>Part end view: part_end_view</p> <p>Part perspective view: part_persp_view</p> <p>3D component view: joint_basic_view</p> <p>Component front view: joint_front_view</p> <p>Component top view: joint_top_view</p> <p>Component end view: joint_end_view</p> <p>Component perspective view: joint_persp_view</p> <p>Custom component front view: custom_object_editor_front_view</p> <p>Custom component top view: custom_object_editor_top_view</p>	View properties

File or file name extension	Description	For more information
	Custom component end view: custom_object_editor_end_view Custom component perspective view: custom_object_editor_perspective_view 3D assembly or cast unit view: assembly_basic_view Assembly or cast unit front view: assembly_front_view Assembly or cast unit top view: assembly_top_view Assembly or cast unit end view: assembly_end_view Assembly or cast unit back view: assembly_back_view Assembly or cast unit bottom view: assembly_bottom_view Assembly or cast unit perspective view: assebly_persp_view	
*.gvi	Saved properties for creating views along grid lines	Grid view properties
*.rep	Object representation properties	Changing the color and transparency of parts
*.clm	Steel column properties	Steel column properties
*.clm.more	Steel column user-defined attribute properties	
*.prt	Steel beam properties	Steel beam properties
*.prt.more	Steel beam user-defined attribute properties	
*.crs	Orthogonal beam properties	Orthogonal beam properties
*.crs.more	Orthogonal beam user-defined attribute properties	
*.dia	Twin profile properties	Twin profile properties
*.dia.more	Twin profile user-defined attribute properties	
*.cpl	Contour plate properties	Contour plate properties
*.cpl.more	Contour plate user-defined attribute properties	
*.ips	Item properties	Item properties
*.ips.more	Item user-defined attribute properties	
*.cpf	Pad footing properties	Pad footing properties
*.cpf.more	Pad footing user-defined attribute properties	
*.csf	Strip footing properties	Strip footing properties
*.csf.more	Strip footing user-defined attribute properties	

File or file name extension	Description	For more information
*.ccl	Concrete column properties	Concrete column properties
*.ccl.more	Concrete column user-defined attribute properties	
.*.cbm	Concrete beam or concrete polybeam properties	Concrete beam properties
*.cbm.more	Concrete beam or concrete polybeam user-defined attribute properties	
*.csl	Concrete slab properties	Concrete slab properties
*.csl.more	Concrete slab user-defined attribute properties	
*.cpn	Concrete panel properties	Concrete panel properties
*.cpn.more	Concrete panel user-defined attribute properties	
*.ipc	Concrete item properties	Concrete item properties
*.ipc.more	Concrete item user-defined attribute properties	
*.rbr	Reinforcing bar properties	Creating a reinforcing bar
*.rbr.more	Reinforcing bar user-defined attribute properties	
*.rbg	Reinforcing bar group properties	Creating a reinforcing bar group
*.rbg.more	Reinforcing bar group user-defined attribute properties	
*.rcu	Curved reinforcing bar group properties	Creating a curved reinforcing bar group
*.rci	Circular reinforcing bar group properties	Creating a circular reinforcing bar group
*.rbm	Reinforcement mesh properties	Creating a rectangular reinforcement mesh
*.rbm.more	Reinforcement mesh user-defined attribute properties	
*.rbs	Reinforcement strand pattern properties	Creating a reinforcement strand pattern
*.rbs.more	Reinforcement strand pattern user-defined attribute properties	
*.rsp	Reinforcement splice properties	Creating a reinforcement splice
*.rsp.more	Reinforcement splice user-defined attribute properties	
*.admodel	Analysis model properties	Analysis model properties
*.admodel.more	Analysis model user-defined attribute properties	
*.lml	Point load properties	Point load properties

File or file name extension	Description	For more information
*.lm2	Line load properties	Line load properties
*.lm3	Area load properties	Area load properties
*.lm4	Uniform load properties	Uniform load properties
*.m10000028	Wind load properties	Wind load properties
*.lm6	Temperature load properties	Temperature load properties
*.lco	Load combination properties	Load combination properties
*.adnode	Analysis node properties	Analysis node properties
*.adnode.more	Analysis node user-defined attribute properties	
*.prt_ad, *.prt_design	File types associated with steel beam analysis property settings. *.prt_ad contains information associated with the analysis part properties and *.prt_design contains information associated with the actual steel beam design.	
*.crs_ad, *.crs_design	File types associated with orthogonal steel beam analysis property settings. *.crs_ad contains information associated with the analysis part properties and *.crs_design contains information associated with orthogonal steel beam design.	
*.clm_ad, *.clm_design	File types associated with steel column analysis property settings. *.clm_ad contains information associated with the analysis part properties and *.clm_design contains information associated with the actual steel column design.	
*.dia_ad, *.dia_design	File types associated with steel twin profile analysis property settings. *.dia_ad contains information associated with the analysis part properties and *.dia_design contains information associated with actual twin profile design.	
*.cpl_ad, *.cpl_design	File types associated with contour plate analysis property settings. *.cpl_ad contains information associated with the analysis part properties and *.cpl_design contains information associated with actual contour plate design.	

File or file name extension	Description	For more information
*.cpf_ad, *.cpf_design	File types associated with pad footing analysis property settings. *.cpf_ad contains information associated with the analysis part properties and *.cpf_design contains information associated with the actual pad footing design.	
*.csf_ad, *.csf_design	File types associated with strip footing analysis property settings. *.csf_ad contains information associated with the analysis part properties and *.csf_design contains information associated with the actual strip footing design.	
*.ccl_ad, *.ccl_design	File types associated with concrete column analysis property settings. *.ccl_ad contains information associated with the analysis part properties and *.ccl_design contains information associated with the actual concrete column design.	
*.cbm_ad, *.cbm_design	File types associated with concrete beam analysis property settings. *.cbm_ad contains information associated with the analysis part properties and *.cbm_design contains information associated with the actual concrete beam design.	
*.csl_ad, *.csl_design	File types associated with concrete slab analysis property settings. *.csl_ad contains information associated with the analysis part properties and *.csl_design contains information associated with the actual slab design.	
*.cpl_ad, *.cpl_design	File types associated with concrete panel analysis property settings. *.cpl_ad contains information associated with the analysis part properties and *.cpl_design contains information associated with the actual concrete panel design.	
*.srf	Surface treatment properties	Adding surface treatment
*.srf.more	User-defined surface treatment attribute properties	
*.cha	Edge chamfer properties	Edge chamfer properties
*.cha.more	User-defined edge chamfer attribute properties	
.scr	Bolt properties	Bolt properties
.scr.more	User-defined bolt attribute properties	
*.wld	Weld properties	Weld properties
*.wld.more	User-defined weld attribute properties	
*.m1000009	Control number properties	Control number settings

File or file name extension	Description	For more information
*.m1000010	Control number locking properties	Locking and unlocking control numbers
*.num	Numbering setup properties	General numbering settings
*.rpr	Report properties	Report settings
*.4d	Project status visualization properties	Project Status Visualization
standard.opt	Settings are saved in <code>standard.opt</code> in the <code>\attributes</code> folder only when you save your own settings in the Options dialog box using Save . There is a <code>standard.opt</code> file in the environment folder that gives the initial values to be loaded when a model is created.	Settings in the Options dialog box on page 19
ComponentCatalogTreeView.txt	Includes the default settings of the folder view in the component catalog.	Grouping components in the Component Catalog
Files in the \PublicWeb folder:		
Model.xml	Web Viewer model in XML format	Tekla Web Viewer
index.html	Index file for the Web Viewer model	
Model.zsol	Contains information on solid objects in the Web Viewer model	
Files in the css folder	Contains Cascading Style Sheet (CSS) files for the Web Viewer Model	
Files in the dll folder	Contains dynamic link libraries (DLL) files for the Web Viewer model	
Files in the help folder	Contains Web Viewer help and css files.	
Files in the images folder	Contains image files used in Web Viewer	
Files in the \drawings folder:		
*.dg	Drawing files	Saving drawings About drawing files
*.ldb	Drawing export layer properties	
Common drawing files:		

File or file name extension	Description	For more information
*.ldr	Drawing link properties	Adding links to other drawings
*.cs	Section symbol properties	Creating a section view
*.detail	Detail symbol properties	Creating a detail view
*.fas	Text file properties	Adding links to text files
*.fhl	Hyperlink properties	Adding hyperlinks
Files related to single-part drawings, drawing level properties, saved in \attributes folder:		
*.wd	Single-part drawing properties	Drawing properties
*.wd.copt	Single-part drawing detailed object level settings	
*.wd.more	Single-part drawing user-defined attributes	
*.wdf	Single-part drawing filter properties	Filtering in drawings
*.wdnf	Single-part drawing neighbor part filter properties	
*.wdl	Single-part drawing layout properties	Drawing layout
*.wdl.more	Single-part drawing user-defined layout attributes	
*.wdv	Single-part drawing view properties	View properties in drawings
*.wdv.more	Single-part drawing user-defined view attributes	
*.wdc	Single-part drawing section view properties	Section view properties
*.wdc.more	Single-part drawing user-defined section view attributes	
*.wdd	Single-part drawing dimension properties	Dimension and dimensioning properties
*.wdd.more	Single-part drawing user-defined dimension attributes	
*.wdcd	Single-part drawing dimensioning properties	
*.wdcd more	Single-part drawing user-defined dimensioning attributes	
*.wpm	Single-part drawing part mark properties	Part mark elements
*.wsm	Single-part drawing bolt mark properties	Bolt mark elements
*.wnpm	Single-part drawing neighbor part mark properties	Part mark elements
*.wdsurfm	Single-part drawing surface treatment mark properties	Surface treatment mark elements
*.wdsurfm.more	Single-part drawing user-defined surface treatment mark attributes	

File or file name extension	Description	For more information
*.wjm	Single-part drawing connection mark properties	Connection mark elements
*.wdp	Single-part drawing part properties	Part and neighbor part properties
*.wds	Single-part drawing bolt properties	Bolt content and appearance properties in drawings
*.wds.more	Single-part drawing user-defined bolt attributes	
*.wdnp	Single-part drawing neighbor part properties	Part and neighbor part properties
*.wdnp.more	Single-part drawing user-defined neighbor part attributes	
*.wdsrf	Single-part drawing surface treatment properties	Surface treatment visibility and content properties in drawings
*.wdsrf.more	Single-part drawing user-defined surface treatment attributes	
*.wdgr	Single-part drawing grid properties	Drawing grid properties
*.wdgr.more	Single-part drawing user-defined grid attributes	Drawing grid properties
*.wdr	Single-part drawing protection properties	Protecting areas in drawings
*.wdr.more	Single-part drawing user-defined protection attributes	Protecting areas in drawings
Files related to assembly drawings, drawing level properties, saved in \attributes folder:		
*.ad	Assembly drawing properties	Drawing properties
*.ad.copt	Assembly drawing detailed object level settings	
*.ad.more	Assembly drawing user-defined attributes	
*.adf	Assembly drawing filter properties	Filtering in drawings
*.adnf	Assembly drawing neighbor part filter properties	
*.adl	Assembly drawing layout properties	Drawing layout
*.adl.more	Assembly drawing user-defined layout attributes	
*.adv	Assembly drawing view properties	View properties in drawings
*.adc	Assembly drawing section view properties	Section view properties

File or file name extension	Description	For more information
*.add	Assembly drawing dimension properties	Dimension and dimensioning properties
*.add.more	Assembly drawing user-defined dimension attributes	
*.adcd	Assembly drawing dimensioning properties	
*.adcd.more	Assembly drawing user-defined dimensioning attributes	
*.apm	Assembly drawing part mark properties	Part mark elements
*.asm	Assembly drawing bolt mark properties	Bolt mark elements
*.anpm	Assembly drawing neighbor part mark properties	Part mark elements
*.adsurfm	Assembly drawing surface treatment mark properties	Surface treatment mark elements
*.adsurfm.more	Assembly drawing user-defined surface treatment mark attributes	
*.ajm	Assembly drawing connection mark properties	Connection mark elements
*.adp	Assembly drawing part properties	Part and neighbor part properties
*.adp.more	Assembly drawing user-defined part attributes	
*.ads	Assembly drawing bolt properties	Bolt content and appearance properties in drawings
*.adnp	Assembly drawing neighbor part properties	Part and neighbor part properties
*.adnp.more	Assembly drawing user-defined neighbor part attributes	
*.adsrf	Assembly drawing surface treatment properties	Surface treatment visibility and content properties in drawings
*.adsrf.more	Assembly drawing user-defined surface treatment attributes	
*.adw	Assembly drawing welding properties	Model weld mark visibility and appearance properties in drawings
*.adw.more	Assembly drawing user-defined welding attributes	
*.adgr	Assembly drawing grid properties	Drawing grid properties

File or file name extension	Description	For more information
*.adgr.more	Assembly drawing user-defined grid attributes	Drawing grid properties
*.adr	Assembly drawing protection properties	Protecting areas in drawings
Files related to cast unit drawings, drawing level properties, saved in \attributes folder:		
*.cud	Cast unit drawing properties	Drawing properties
*.cud.copt	Cast unit drawing detailed object level settings	
*.cud.more	Cast unit drawing user-defined attributes	
*.cudl	Cast unit drawing layout properties	Drawing layout
*.cudl.more	Cast unit drawing user-defined layout attributes	
*.cudv	Cast unit drawing view properties	View properties in drawings
*.cudv.more	Cast unit drawing user-defined view attributes	
*.cudc	Cast unit drawing section view properties	Section view properties
*.cudc.more	Cast unit drawing user-defined section view attributes	
*.cudd	Cast unit drawing dimension properties	Dimension and dimensioning properties
*.cudd.more	Cast unit drawing user-defined dimension attributes	
*.cuded	Cast unit drawing dimensioning properties	
*.cuded.more	Cast unit drawing user-defined dimensioning properties	
*.cupm	Cast unit drawing part mark properties	Part mark elements
*.cusm	Cast unit drawing bolt mark properties	Bolt mark elements
*.cunpm	Cast unit drawing neighbor part mark properties	Part mark elements
*.cudsurfm	Cast unit drawing surface treatment mark properties	Surface treatment mark elements
*.cudsurfm.more	Cast unit drawing user-defined surface treatment mark attributes	
*.cudrm	Cast unit drawing reinforcement mark properties	Reinforcement and neighbor reinforcement mark elements
*.cudrm.more	Cast unit drawing user-defined reinforcement mark attributes	
		Mark properties

File or file name extension	Description	For more information
*.cudp	Cast unit drawing part properties	Part and neighbor part properties
*.cudp.more	Cast unit drawing user-defined part attributes	
*.cuds	Cast unit drawing bolt properties	Bolt content and appearance properties in drawings
*.cuds.more	Cast unit drawing user-defined bolt attributes	
*.cudnp	Cast unit drawing neighbor part properties	Part and neighbor part properties
*.cudnp.more	Cast unit drawing user-defined neighbor part attributes	
*.cudsurf	Cast unit drawing surface treatment properties	Surface treatment visibility and content properties in drawings
*.cudsurf.more	Cast unit drawing user-defined surface treatment attributes	
*.cudr	Cast unit drawing reinforcement properties	Reinforcement/ Neighbor reinforcement and mesh properties in drawings
*.cudr.more	Cast unit drawing user-defined reinforcement attributes	
*.cudw	Cast unit drawing welding properties	Model weld mark visibility and appearance properties in drawings
*.cudw.more	Cast unit drawing user-defined welding attributes	
*.cudgr	Cast unit drawing grid properties	Drawing grid properties
*.cudgr.more	Cast unit drawing user-defined grid attributes	Drawing grid properties
*.cudrp	Cast unit drawing protection properties	Protecting areas in drawings
*.cudrp.more	Cast unit drawing user-defined protection attributes	Protecting areas in drawings
*.cuf	Cast unit drawing filter properties	Filtering in drawings
*.cunf	Cast unit drawing neighbor part filter properties	
Files related to multidrawings, drawing level properties, saved in \attributes folder:		
*.md	Multidrawing properties	Drawing properties
*.md.more	Multidrawing user-defined attributes	

File or file name extension	Description	For more information
*.mdl	Multidrawing layout properties	Drawing layout
*.mdl.more	Multidrawing user-defined layout attributes	
*.mdr	Multidrawing protection properties	Protecting areas in drawings
*.mdr.more	Multidrawing user-defined protection attributes	Protecting areas in drawings
Files related to general arrangement drawings, drawing level properties, saved in \attributes folder:		
*.gd	General arrangement drawing properties	Drawing properties
*.gd.copt	General arrangement drawing detailed object level settings.	
*.gd.more	General arrangement drawing user-defined properties	
*.gdl	General arrangement drawing layout properties	Drawing layout
*.gdl.more	General arrangement drawing user-defined layout attributes	
*.gdv	General arrangement drawing view properties	View properties in drawings
*.gdv.more	General arrangement drawing user-defined view attributes	
*.gdd	General arrangement drawing dimension properties	Dimension and dimensioning properties
*.gdd.more	General arrangement drawing user-defined dimension attributes	
*.gdcd	General arrangement drawing dimensioning properties	
*.gdcd.more	General arrangement drawing user-defined dimensioning attributes	
*.gpm	General arrangement drawing part mark properties	Part mark elements
*.gsm	General arrangement drawing bolt mark properties	Bolt mark elements
*.gnpm	General arrangement drawing neighbor part mark properties	Part mark elements
*.gdsurfm	General arrangement drawing surface treatment mark properties	Surface treatment mark elements
*.gdsurfm.more	General arrangement drawing user-defined surface treatment mark attributes	
*.gjm	General arrangement drawing connection mark properties	Connection mark elements
*.gdrm	General arrangement drawing reinforcement mark properties	Reinforcement and neighbor

File or file name extension	Description	For more information
*.gdrm.more	General arrangement drawing user-defined reinforcement mark attributes	reinforcement mark elements Mark properties
*.gdp	General arrangement drawing part properties	Part and neighbor part properties
*.gdp.more	General arrangement drawing user-defined part attributes	
*.gds	General arrangement drawing bolt properties	Bolt content and appearance properties in drawings
*.gds.more	General arrangement drawing user-defined bolt attributes	
*.gdnpp	General arrangement drawing neighbor part properties	Part and neighbor part properties
*.gdnpp.more	General arrangement drawing user-defined neighbor part attributes	
*.gdsrf	General arrangement drawing surface treatment properties	Surface treatment visibility and content properties in drawings
*.gdw	General arrangement drawing welding properties	Model weld mark visibility and appearance properties in drawings
*.gdw.more	General arrangement drawing user-defined welding attributes	
*.gdr	General arrangement drawing reinforcement properties	Reinforcement/Neighbor reinforcement and mesh properties in drawings
*.gdr.more	General arrangement drawing user-defined reinforcement attributes	
*.gdrmp	General arrangement drawing reference object properties	Setting the visibility and appearance of reference models in drawings...
*.gdrmp.more	General arrangement drawing user-defined reference model attributes	Setting the visibility and appearance of reference models in drawings...
*.gdgr	General arrangement drawing grid properties	Drawing grid properties

File or file name extension	Description	For more information
*.gdgr.mor e	General arrangement drawing user-defined grid attributes	Drawing grid properties
*.gdrp	General arrangement drawing protection properties	Protecting areas in drawings
*.gdrp.mor e	General arrangement drawing user-defined protection attributes	Protecting areas in drawings
*.gdf	General arrangement drawing filter properties	Filtering in drawings
*.gdnf	General arrangement drawing neighbor part filter properties	
View level drawing settings, saved in \attributes folder:		
*.vi	View level view properties	View properties in drawings
*.vi.copt	View level detailed object level settings	View properties in drawings
*.vpm	View level part mark properties	Part mark elements
*.vsm	View level bolt mark properties	Bolt mark elements
*.vnpm	View level neighbor part mark properties	Part mark elements
*.vsurfm	View level surface treatment mark properties	Surface treatment mark elements
*.vjm	View level connection mark properties	Connection mark elements
*.vrm	View level reinforcement mark properties	Reinforcement and neighbor reinforcement mark elements Mark properties
*.vnrm	View level neighbor reinforcement mark properties	Reinforcement and neighbor reinforcement mark elements Mark properties
*.vp	View level part properties	Part and neighbor part properties
*.vs	View level bolt properties	Bolt content and appearance

File or file name extension	Description	For more information
		properties in drawings
*.vnp	View level neighbor part properties	Part and neighbor part properties
*.vsurf	View level surface treatment properties	Surface treatment visibility and content properties in drawings
*.vw	View level welding properties	Model weld mark visibility and appearance properties in drawings
*.vr	View level reinforcement properties	Reinforcement/Neighbor reinforcement and mesh properties in drawings
*.vnr	View level neighbor reinforcement properties	Reinforcement/Neighbor reinforcement and mesh properties in drawings
*.vrmp	View level reference object properties	Setting the visibility and appearance of reference models in drawings...
*.vg	View level grid properties	Drawing grid properties
*.vf	View level filter properties	Filtering in drawings
*.vnf	View level neighbor part filter properties	
Object level settings, saved in \attributes folder:		
*.dprt	Object level part properties	Part and neighbor part properties

File or file name extension	Description	For more information
*.dim	Object level dimension properties	Dimension and dimensioning properties
*.pm	Object level part mark properties	Mark properties
*.jm	Object level connection mark properties	
*.sm	Object level bolt mark properties	
*.rm	Object level reinforcement mark properties	
*.mrms	Object level merged reinforcement mark properties	
*.surfm	Object level surface treatment mark properties	
*.note	Object level associative note properties	
*.wls	Object level weld mark properties	
*.lev	Object level level mark properties	Level mark properties
*.rev	Object level revision mark properties	Adding revision marks
*.drmsH	Object level reinforcement mesh properties	Reinforcement/ Neighbor reinforcement and mesh properties in drawings
*.drbr	Object level reinforcement properties	Reinforcement/ Neighbor reinforcement and mesh properties in drawings
*.sc	Object level bolt properties	Bolt content and appearance properties in drawings
*.srf	Object level surface treatment properties	Surface treatment visibility and content properties in drawings
*.dgr	Object level grid properties	Drawing grid properties

File or file name extension	Description	For more information
*.sbl	Object level symbol properties	Symbols in drawings
*.wls	Object level weld mark properties	Adding weld marks
*.drtxt	Object level text properties	Adding text
*.gln	Object level line properties	Creating a shape in a drawing
*.grt	Object level rectangle properties	
*.gci	Object level circle properties	
*.gar	Object level arc properties	
*.gpl	Object level polyline properties	
*.gpg	Object level polygon and cloud properties	
Other drawing related files saved in \attributes folder		
.dsf	Drawing selection filter properties. This file is saved when you select DrawingSelection filter in the Filter panel of in the Filter properties dialog box.	Filtering in drawings
Files in the \Reports folder:		
*.xsr	Tekla Structures reports	Reports
Files in the \ShapeGeometries folder:		
*.xml	Shape geometry descriptions	Importing a shape
Files in the \Shapes folder:		
*.xml	Shape descriptions	Shapes
Files in the \DSTV_Profiles folder:		
*.nc1	NC (numerical control) files	NC files

In addition, Tekla Structures generates, for example, the following files depending on what functionalities you are using:

- Properties files for components available in the **Component Catalog**, for example *.j310000063 for **2L Splice (63)** component properties. These files are stored in the `attributes` folder under the model folder
- Files related to Unitechnik export in the `UT_files` folder under the model folder.

3.15 Checking and changing Tekla Structures file and folder locations (Directory Browser)

Directory Browser is a tool that helps you to find and modify the location of the various Tekla Structures files and folders, and customize user settings.



Generally, only administrators should change these settings. If you change them yourself, and you are using the same model with other users, and your settings differ from those of the project, you will have problems. Also, adding or modifying files in some of these folders may require administrator rights.

To locate files and folders, and customize your Tekla Structures settings:

1. Select **Tools** --> **Macros...** to open the **Macros** dialog box.
2. Select `DirectoryBrowser` and click **Run**.


The **Directory Browser** dialog box is displayed. Here you can check the most common folder paths, and customize the settings in your `user.ini` file, or in the user-specific or model-specific `options.ini` file.

3. Check the folder paths and change them if necessary by clicking the buttons on the left of the **Basic** tab.

If you click the **Project** or **Firm** button and you have not set your firm and project folder, Tekla Structures will prompt you to do so and add the folder path definition to your `user.ini` file.

4. Check the settings in the `user.ini` and `options.ini` files and change them if necessary by clicking the buttons on the right of the **Basic** tab.
5. Go to the **Advanced** tab and define the folder paths for additional folders that you may need to access, such as custom components and macros.

Example To display the location of your own user settings, click **User Settings** on the left. If you want to check or change the content in one of your user settings files, click the **User Settings** (`user.ini`) or the **User Specific Settings** (`options.ini`) button to open the file.



3.16 Folder search order

When you open a model, Tekla Structures searches for the associated files in specific folders in a set order.

It is important that you keep files in correct folders. Once Tekla Structures finds the associated files, it stops searching. This means that files that have the same name but are located lower down the search order are ignored.

The folder search order is:

Folder	Defined by
Current model	The open model
Project	Advanced option XS_PROJECT
Firm	Advanced option XS_FIRM

Folder	Defined by
System	Advanced option XS_SYSTEM

Tekla Structures does not search for certain files in exactly this order. The exceptions are listed below.

The exceptions are:

File (type)	Search order
objects.inp	<ul style="list-style-type: none"> • Model folder • Project folder (XS_PROJECT) • Firm folder (XS_FIRM) • System folder (XS_SYSTEM) • inp folder (XS_INP)
privileges.inp	<ul style="list-style-type: none"> • Model folder • Project folder (XS_PROJECT) • Firm folder (XS_FIRM) • System folder (XS_SYSTEM) • inp folder (XS_INP)
*.dat files	System folder (XS_SYSTEM)
Templates	<ul style="list-style-type: none"> • Folder containing your templates indicated by the advanced option XS_TEMPLATE_DIRECTORY • Model folder • Project folder (XS_PROJECT) • Firm folder (XS_FIRM) • Environment-specific system templates indicated by the advanced option XS_TEMPLATE_DIRECTORY_SYSTEM • System folder (XS_SYSTEM)
Catalogs	<p>Profile, bolt, material and reinforcement catalogs:</p> <ul style="list-style-type: none"> • Model folder • Project folder (XS_PROJECT) • Firm folder (XS_FIRM) • Folder indicated by the advanced option XS_PROFDB <p>Shape catalog:</p> <ul style="list-style-type: none"> • Model folder • Project folder (XS_PROJECT) • Firm folder (XS_FIRM)

File (type)	Search order
	<ul style="list-style-type: none"> • System folder (XS_SYSTEM) • Folder indicated by the advanced option XS_DEFAULT_BREP_PATH Printer catalog: <ul style="list-style-type: none"> • Model folder • Project folder (XS_PROJECT) • Firm folder (XS_FIRM) • Folder indicated by the advanced option XS_DRIVER



Do not use the system folder to store customized files. That way you will avoid having problems or doing a lot of unnecessary work when you upgrade to a newer version of the software.

3.17 Project and firm folders

You can create project and firm folders for customized files. This is a useful technique if you want to store the files for future use, or want to retain them when you install a new release. The project folder is where you should store files you customize for a particular project. Use the firm folder to store files customized for a particular organization or company. Create firm and project folders manually and make them available in all versions using the advanced options XS_PROJECT and XS_FIRM in **Tools --> Options --> Advanced Options... --> File Locations** .

For example, you regularly work for a company that has specific drawing layout standards it expects you to use. Customize the drawing templates once for the company and save them in a sub-folder located under the firm folder. You can then use the customized drawing templates for all future projects for that company.



Changing an advanced option value in .ini files located outside the model folder does not affect the existing models. You can only update advanced options in the **Advanced Options** dialog box or in the options.ini file located in model folder; not from an options.ini file located in folders defined for the advanced options XS_FIRM or XS_PROJECT. The .ini files are read also when you open an existing model, but only new advanced options that do not exist in options_model.db or options_drawings.db are inserted, for

example, such options that are not yet in the **Advanced Options** dialog box but have been added in the software.

See also [Folder search order on page 84](#)

[Typical initialization files and their reading order on page 10](#)

3.18 Location of environment files

The environment files are by default located in `..\ProgramData\Tekla Structures\<<version>\environments`

See also

3.19 Location of certain files in hidden folders

When Tekla Structures is installed in the `\Program Files` folder the following settings files are located in hidden folders. You can see hidden folders if you turn them visible in Windows **Folder Options**.



You can always check the settings below. If you run into problems with the settings, ask your administrator or local support for assistance.

File	Location
<code>analysis_design_config.inp</code>	<code>..\ProgramData\Tekla Structures\<<version>\environments\<<environment>\system</code>
<code>contentattributes.lst</code>	<code>..\ProgramData\Tekla Structures\<<version>\environments\<<environment>\template\settings</code>
<code>contentattributes_global.lst</code>	<code>..\Program Files\Tekla Structures\<<version>\nt\TplEd\settings</code>
<code>contentattributes_userdefined.lst</code> (in USImperial and Metric environments: <code>contentattributes_customer.lst</code>)	<code>..\Program Files\Tekla Structures\<<version>\nt\TplEd\settings</code>

File	Location
dimension_marks.sym	..\ProgramData\Tekla Structures\ <version>\environments\common\symbols</version>
InquiryTool.config	..\ProgramData\Tekla Structures\ <version>\environments\common\macros\modeling\ \InquiryToolAttributes</version>
objects.inp	..\ProgramData\Tekla Structures\ <version>\environments\common\inp</version>
options.bin	..\Users\ <user>\AppData\Local\Tekla Structures\<version>\UserSettings</version></user>
privileges.inp	..\ProgramData\Tekla Structures\ <version>\environments\common\inp</version>
product_finishes.dat	..\ProgramData\Tekla Structures\ <version>\environments\common\system</version>
rebar_config.inp	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\system</environment></version>
TeklaStructures.lin	..\ProgramData\Tekla Structures\ <version>\environments\common\inp</version>
teklastructures.minitoolbar.xml	..\Users\ <user>\AppData\Local\Tekla Structures\<version>\UserSettings</version></user>
TilePatternCatalog.dtd	..\ProgramData\Tekla Structures\ <version>\environments\common\system</version>
TilePatternCatalog.xml	..\ProgramData\Tekla Structures\ <version>\environments\<environment>\system</environment></version>
user.ini	..\Users\ <username>\AppData\Local\Tekla Structures\<version>\UserSettings\ \</version></username>

3.20 Macros

In Tekla Structures, you can use the predefined macros available in **Tools --> Macros**, or you can record a series of actions from menus, dialog boxes, or shortcuts. You can also create macro files manually.

Macros are saved as `.cs` files in the `drawings` or `modeling` folder under a folder defined with the advanced option `XS_MACRO_DIRECTORY`. By default, this advanced option is set to `.. \ProgramData \Tekla Structures \<version> \environments \common \macros`. In addition to this global folder, you can create a local folder and save your macros there. You can add your own folder for this advanced option in addition to the global folder.

See also [Recording, editing and running macros on page 89](#)

[Adding a customized toolbar button for a macro on page 90](#)

[Checking and changing Tekla Structures file and folder locations \(Directory Browser\) on page 82](#)

Recording, editing and running macros

To record and edit a macro and then run it:

1. Click **Tools --> Macros** to open the **Macros** dialog box.
2. Enter a name for the macro in the **Macro name** box.

Once you enter the name, the **Record** button is activated.

3. Click the **Global** or **Local** option button depending on whether you want to save the macro in the global or local macros folder.

The **Global** and **Local** option buttons are only available if you have defined a location for the local macros in your environment using the advanced option `XS_MACRO_DIRECTORY`.

4. Click **Record**.
5. Perform the actions you want to record.
6. Click **Stop** to stop recording.

The recorded macro is saved under global or local macros in the `\drawings` or `\modeling` folder depending on the mode (drawing or modeling) you were using while you were recording the macro.

7. To view or edit the macro you created, select the macro and click **Edit**.

The macro can be opened in any text editor.

8. To run the macro, select it and click **Run**.



To manually create a macro file, click **Create** in the **Macros** dialog box. This creates an empty macro file, which you can manually edit, for example, by copying commands in it from other macro files.

See also [Adding a customized toolbar button for a macro on page 90](#)
[Macros on page 88](#)

Adding a customized toolbar button for a macro

You can create your own toolbar buttons for macros and have them available on user-specific toolbars.

To add a customized toolbar button:

1. Create the bitmap you want to use as the toolbar button.
2. Save the bitmap with the same name as the macro in the same folder as the macro.
For example, if you have a macro that is used in modeling, and the name of the macro is `RotatePart.cs`, save the bitmap as `RotatePart.bmp` in the folder `.. \Tekla Structures \<version> \environments \common \macros \modeling`.
If you are using large toolbar buttons (24x24 pixels instead of 16x16 pixels), add the suffix `_big` to the bitmap name: for example, `RotatePart_big.bmp`.
3. Click **Tools** --> **Customize** to open the **Customize** dialog box.
4. If you have not created any user-specific toolbars, click **New** to create one.
5. Enter `macro` in the **Filter** box to list the available macros.
6. Select the macro from the list, click the user-specific toolbar in the **Toolbars** list, and then click the right arrow.
The macro is added to the user-specific toolbar.
7. Click **Close** to close the **Customize** dialog box.
8. Restart Tekla Structures to load the bitmap.

4 Model dump

If you have fatal problems with the model, for example, you cannot save the model, using a model dump is one way of saving your work. Model dump creates an ASCII file. The file contains your entire model including views and drawings.



The following information is for advanced users.

You can modify a model dump file with a standard text editor. For example, if you know the ID of a corrupted part, you can search for the ID in the file and delete the data related to the ID.

See also [Importing a model dump on page 91](#)
[Exporting a model dump on page 91](#)

4.1 Exporting a model dump

Exporting a model dump creates an ASCII file of a model. You can import the model dump into a new model. The model dump file contains the entire model, including views and drawings.

To export a model into a model dump file, click **File --> Export --> Model Dump**.

Tekla Structures creates the `model.dmp` file in the model folder.

See also [Importing a model dump on page 91](#)

4.2 Importing a model dump

You can only import a model dump into a newly-created model. A model dump can be imported only once into one model. You can import the same model dump into several new models.

To import a model dump:

1. Create a new model.
2. Copy the model dump file (.dmp) to the new model's model folder.
3. Click **File --> Import --> Model Dump**.
4. Save and close the model.
5. Reopen the model.



Do not import model dumps in multi-user mode.

See also [Exporting a model dump on page 91](#)

5 Disclaimer

© 2015 Tekla Corporation and its licensors. All rights reserved.

This Software Manual has been developed for use with the referenced Software. Use of the Software, and use of this Software Manual are governed by a License Agreement. Among other provisions, the License Agreement sets certain warranties for the Software and this Manual, disclaims other warranties, limits recoverable damages, defines permitted uses of the Software, and determines whether you are an authorized user of the Software. All information set forth in this manual is provided with the warranty set forth in the License Agreement. Please refer to the License Agreement for important obligations and applicable limitations and restrictions on your rights. Tekla does not guarantee that the text is free of technical inaccuracies or typographical errors. Tekla reserves the right to make changes and additions to this manual due to changes in the software or otherwise.

In addition, this Software Manual is protected by copyright law and by international treaties. Unauthorized reproduction, display, modification, or distribution of this Manual, or any portion of it, may result in severe civil and criminal penalties, and will be prosecuted to the full extent permitted by law.

Tekla, Tekla Structures, Tekla BIMsight, BIMsight, Tedds, Solve, Fastrak and Orion are either registered trademarks or trademarks of Tekla Corporation in the European Union, the United States, and/or other countries. More about Tekla trademarks: <http://www.tekla.com/tekla-trademarks>. Trimble is a registered trademark or trademark of Trimble Navigation Limited in the European Union, in the United States and/or other countries. More about Trimble trademarks: <http://www.trimble.com/trademarks.aspx>. Other product and company names mentioned in this Manual are or may be trademarks of their respective owners. By referring to a third-party product or brand, Tekla does not intend to suggest an affiliation with or endorsement by such third party and disclaims any such affiliation or endorsement, except where otherwise expressly stated.

Portions of this software:

D-Cubed 2D DCM © 2010 Siemens Industry Software Limited. All rights reserved.

EPM toolkit © 1995-2004 EPM Technology a.s., Oslo, Norway. All rights reserved.

Open CASCADE Technology © 2001-2014 Open CASCADE SA. All rights reserved.

FLY SDK - CAD SDK © 2012 VisualIntegrity™. All rights reserved.

Teigha © 2003-2014 Open Design Alliance. All rights reserved.

PolyBoolean C++ Library © 2001-2012 Complex A5 Co. Ltd. All rights reserved.

FlexNet Copyright © 2014 Flexera Software LLC. All Rights Reserved.

This product contains proprietary and confidential technology, information and creative works owned by Flexera Software LLC and its licensors, if any. Any use, copying, publication, distribution, display, modification, or transmission of such technology in whole or in part in any form or by any means without the prior express written permission of Flexera Software LLC is strictly prohibited. Except where expressly provided by Flexera Software LLC in writing, possession of this technology shall not be construed to confer any license or rights under any Flexera Software LLC intellectual property rights, whether by estoppel, implication, or otherwise.

To see the third party licenses, go to Tekla Structures, click **Help** --> **About** and click the **Third party licenses** button.

The elements of the software described in this Manual are protected by several patents and possibly pending patent applications in the European Union and/or other countries. For more information go to page <http://www.tekla.com/tekla-patents>.

Index

A

advanced options.....	10
changing.....	37
storing settings.....	18
user-specific.....	33
API.....	8

C

catalog files.....	53
clash check	
settings.....	19
company.ini.....	10
components	
settings.....	19
creating	
customized initialization files.....	16
shortcuts.....	16
customized initializations.....	16
customizing	
message files.....	50
user-defined attributes.....	39

D

data files.....	49
decimals	
settings.....	19
defining	
flat bar sizes.....	46
unfolding parameters.....	47
dimensions	
default format.....	19
default precision.....	19
default unit.....	19
settings.....	19
drawing objects	
settings.....	19

E

environment settings	
global default	13
local.....	14
environment variables.....	18
see advanced options.....	37
environment variables, see advanced options.....	10
environment.db.....	40
environment	
database file.....	40
env_<environment>.ini.....	10,14,32
env_global_default.ini.....	10,32
env_global_default.ini	13
examples	
creating user-defined attribute.....	43
flat bar sizes.....	46
modifying messages.....	51
updating user-defined attribute.....	43
exporting	
model dump.....	91
extensions.....	8

F

file name extensions.....	62
file types	
initialization files.....	10
files.....	9
extensions.....	62
in model folder.....	62
initialization files.....	10
locations.....	82
symbol.....	55
firm folder.....	86
flat bars	
in drawings	46
in reports.....	46
sizes.....	46
fltprops.inp.....	46
folders.....	9

firm.....	86
in model folder.....	62
locations.....	82
project.....	86
search order.....	84
font files.....	54
fonts.....	54
fonts_<lang>.ini.....	10

G

global default environment settings.....	13
graphics card.....	5

I

icons	
adding customized toolbar buttons.....	90
image files.....	56
images	
file formats.....	56
importing	
model dump.....	91
ini files.....	10,16
env_global_default.ini.....	13,14
role_<role>.ini.....	14
initialization files.....	10
creating customized.....	16
env_<environment>.ini.....	14
env_global_default.ini.....	13
file types.....	10
including other initialization files	18
reading order.....	10
role_<role>.ini.....	14
usage.....	10
input files.....	38

L

lang_<lang>.ini.....	10
load modeling	
settings.....	19
local environment settings	
env_<environment>.ini.....	14
location	
of environmental files.....	87

of hidden files.....	87
locations	
files.....	82
folders.....	82
log files	
list of.....	57
numbering.history log.....	59,61
viewing.....	58
viewing parts.....	58

M

macros.....	88
adding customized toolbar buttons.....	90
editing.....	89
global.....	89
local.....	89
recording.....	89
running.....	89
memory.....	5
message files.....	50
customizing.....	50
messages	
modifying.....	51
Migration Wizard.....	15
model dump.....	91
exporting.....	91
importing.....	91
model folder	
file name extensions.....	62
files.....	62
model-specific settings.....	32
mouse	
settings.....	19

N

north marks, see orientation marks.....	19
numbering history.....	59,61
numbering	
settings.....	19
user-defined attributes.....	43

O

objects.inp.....	41
------------------	----

optimizing	
Tekla Structures performance.....	5
Options dialog box	
settings.....	19
options.bin.....	10,18,32,33,37
options.ini.....	10,32
options	
storing saving.....	18
options_drawings.db.....	18,19,32,37
options_model.db.....	18,19,32,37
orientation marks	
settings.....	19

P

performance	
modeling tips.....	6
optimizing.....	5
plates	
flat bars.....	46
plotdev.bin.....	55
profile files.....	53
project folder.....	86
properties files.....	52
properties	
objects.inp.....	41
unfolding parameters.....	48
property files.....	51

R

reading order	
initialization files.....	10
recording	
macros.....	89
report files.....	55
role settings.....	14
roles.....	14
role_<role>.ini.....	10,14,32
running	
macros.....	89

S

saving	
advanced options.....	18

options.....	18
search order.....	84
settings	
clash check.....	19
components.....	19
decimals.....	19
dimensions.....	19
drawing objects.....	19
general.....	19
in the Options dialog box.....	19
load modeling.....	19
mouse.....	19
north marks, see orientation marks.....	19
orientation marks.....	19
startup.....	19
units.....	19
shortcuts	
creating.....	16
customized initialization files.....	18
standard files.....	51
creating.....	52
saving.....	52
standard.opt.....	19
startup	
settings.....	19
symbol files.....	55
system-specific settings.....	32

T

Tekla Open API.....	8
Tekla Structures files.....	9
Tekla Structures folders.....	9
teklastructures.ini.....	10
template files.....	55
tips	
modeling large models.....	6
toolbars	
adding toolbar buttons for macros.....	90

U

unfolding parameters	
defining.....	47
properties.....	48
unfold_corner_ratios.inp.....	48
units	

settings.....	19
updating	
user-defined attributes in model.....	40
user-defined attributes	
customizing.....	39
environment.db.....	40
example.....	43
numbering.....	43
objects.inp properties.....	41
updating in model.....	40
user-specific advanced options.....	33
user-specific settings.....	32
user.ini.....	10
modifying.....	15

V

variables	
see advanced options.....	33
viewing parts	
in log files.....	58
viewing	
log files.....	58